
SEAHAWK
- SINCE 1978 -

GREYHOUND

3000 / 4000 / 5000



PARTS LIST

PAPTS NO	PAPTS NAME
1	DARG KNOB CAP
2	DRAG KNOB
3	DRAG CLICK CLAW
4	DRAG NUT
5	DRAG SRING
6	DRAG BUSHING
7	DRAG PLATE
8	DRAG SCREW
9	SPOOL RING
10	SPOOL "D"W/S
11	SPOOL "A"W/S
12	SPOOL W/S
13	SPOOL
14	LINE CLIP
15	MAIN SHAFT W/S
16	CLICK GEAR
17	SPOOL CLICK CLAW
18	SPOOL CLICK CLAW S/C
19	LINE CLIP S/C
20	ARM LEVER COVER
21	ROTOR COVER S/C
22	ROTOR
23	BAIL HOLDER
24	BAIL SCREW
25	ARM LEVER
26	LINE ROLLER W/S
27	LINE ROLLER
28	BALL BEARING BEARING-
29	LINE SLIDER
30	BAIL ARM
31	ARMLEVER S/C
32	ARM LEVER SHAFT
33	ARM LEVER SPRING
34	KICK LEVER
35	SQUARE SIDE S/C
36	SQUARE SIDE
37	MAIN SHAFT
38	BALL BEARING
39	ONE-WAY
40	ONE-WAY SPRING
41	PINION
42	STOPPER LEVER S/P
43	STOPPER LEVER SHAFT
44	STOPPER LEVER
45	STOPPER LEVER S/C
46	ONE-WAY INSIDE TRACK
47	HANDLE ASSY
48	PINION BEARING ROTOR W/S S/C
49	BODY DECK
50	HANDLE CAP
51	BODY COVER
52	BODY CAP
53	BODY COVER S/C "A"
54	O/S GEAR
55	O/S SLIDER
56	O/S GEAR S/C
57	BALL BEARING
58	DRIVE GRAR
59	DRIVE GEAR W/S
60	BALL BEARING
61	BODY
62	O/S SLIDER FIX
63	O/S GEAR S/C
64	ROTOR W/S
65	PINION BEARING SHEATH
66	PINION BEARING ROTOR W/S
67	BODY CAP S/C
68	ROTOR NUT FIXING SLEEVE
69	RUBBER WATERPROOF RING
70	ROTOR NUT
71	ROTOR CAP
72	ONE-WAY SHELL
73	ONE-WAY WATERPROOF RING
74	BALL BEARING BEARING
75	BALL BEARING BEARING