
SEAHAWK
- SINCE 1978 -

LITE PRO LTD 800



1. Drag Knob	36. One Way Clutch Ball Bearing
2. Spool Stop Ring	
3. Key Washer	37. Bearing Spring
4. Drag Washer	38. Pinion Gear
5. Eared Washer	39. Spring
6. Spool	40. Screw
7. Line Hook	41. Anti-Reverse Lever
8. Screw	42. Anti-Reverse Bolt
9. Click Gear Washer	43. Body Bearing
10. Click Gear	44. Drive Gear
11. Click Slice	45. Drive Gear Washer
12. Screw	46. Body Cover Bearing
13. Screw	47. Body Cover
14. Rotor Nut	48. Screw
15. Rotor Retainer	49. CNC Handle
16. Rotor	50. Oscillation Gear
17. Bail Holder	51. Slider
18. Bail Arm	52. Screw
19. Screw	53. Handle Cap Washer
20. Screw	54. Handle Cap
21. Bail Arm Side Cover	55. Main Body
22. Screw	56. Slider Retainer Plate
23. Roller Washer	57. Screw
24. Roller Ball Bearing	58. Body Cover
25. Roller Bushing	59. Body Cover
26. Roller	60. Ball Bearing
27. Bail ASSY	61. Aluminium Round Knob
28. Bail Arm Lever	
29. Bail Arm Spring	
30. Rotor Trip Lever	
31. Main Shaft	
32. Ball Bearing Retainer	
33. Pinion Bearing	
34. Bearing Bushing	
35. Bearing Inner Ring	