
SEAHAWK
- SINCE 1978 -
Tampa

EXPLODED VIEW



ReelSchematic

KEY NO	PARTS NAME	KEY NO	PARTS NAME	KEY NO	PARTS NAME	KEY NO	PARTS NAME
1	DRAG KNOB ASSY	19	Screw	37	PINION BEARING FIXED BUSHING	55	OSCILLATING SLIDER
2	DRAG WASHER RETAINER	20	BAIL HOLDER	38	BALL BEARING	56	Screw
3	KEY WASHER	21	BAIL WIRE ASSY	39	PINION BEARING FIXED PLATE	57	BALL BEARING
4	EARED WASHER	22	BAIL WIRE ASSY	40	BALL BEARING	58	DRIVE GEAR
5	DRAG WASHER	23	LINE ROLLER	41	EXTENSION SPRING	59	WASHER
6	Spool	24	BALL BEARING	42	BALL BEARING	60	BALL BEARING
7	Stator	25	LINE ROLLE RWASHER	43	PINION GEAR	61	SIDE PLATE
8	Screw	26	BAIL ARM	44	ANTI-REVERSE/ANTI-RE LEVER	62	Screw
9	Tension spring	27	Screw	45	ANTI-RE LEVER SPRING	63	SIDE PLATE DECORATION
10	Screw	28	Screw	46	ANTI-REVERSE/ANTI-RE LEVER	64	Hex shaft
11	CLICK GEAR WASHER	29	ROTOR	47	Screw	65	Rocker arm
12	CLICK GEAR WASHER	30	KICK LEVER	48	MIAN BODY DECORATION	66	Bolt
13	CLICK GEAR	31	BAIL ARM SLIDER	49	WASHER	67	Rocker arm
14	Screw	32	COMPRESSION SPRING	50	HANDLE CAP	68	Rivet
15	Phonation gear plate	33	BAIL ARM COVER	51	MIAN BODY	69	Handle
16	Hex nut	34	Screw	52	CAP		
17	Stator	35	WASHER	53	Screw		
18	Shaft	36	Screw	54	TRANSMISSION GEAR		