


NO.	PART NAME	NO.	PART NAME	NO.	PART NAME	NO.	PART NAME	NO.	PART NAME
1	FRAME	18	TRANSFER GEAR	35	RIGHT SIDE PLATE	52	GEAR STEM WASHER	69	RIGHT COVER ASS'Y
2	HOOD	19	E-RING	36	CLUTCH CAM	53	SCREW	70	RIGHT COVER SCREW
3	SCREW	20	SPOOL COVER	37	CLUTCH SPRING BUSHING	54	BRAKE RING	71	O-RING
4	WORM SHAFT BUSHING	21	RUBBER WASHER	38	CLUTCH SPRING	55	PINION YOKE	72	O-RING
5	CARRIER GUIDE	22	SPACER	39	PILOT LEVER	56	PINION GEAR	73	TENSION KONB
6	LINE GUIDE CARRIER ASS'Y	23	SCREW	40	STEM	57	PINION GEAR SPRING	74	RUBBER WASHER
7	SHUTTLE SCREW	24	LEFT COVER	41	RETURN PAWL	58	DOG ASS'Y	75	SPACER
8	WORM SHAFT BUSHING	25	BAIT CLICK BUTTON	42	RETURN PAWL SRPING	59	RATCHET	76	SCREW
9	LEFT SIDE PLATE	26	B-CLICK BUTTON SPRING	43	CLUTCH CAM SCREW	60	DRAG WASHER	77	DRAG SPRING WASHER
10	CLICK PAWL LEVER	27	SCREW	44	PUSH BAR	61	DRIVE GEAR	78	STAR DRAG RIVET ASS'Y
11	CLICK PAWL STEM	28	LINE GUIDE PAWL	45	PUSH BAR STEM	62	DRAG WASHER	79	LEAF SPRING
12	CLICK PAWL	29	SPACER	46	E-RING	63	KEYED DRAG WASHER	80	HANDLE ASS'Y
13	E-RING	30	PAWL CAP	47	BUSHING	64	EARED WASHER	81	HANDLE NUT
14	CLICK SPRING	31	SPOOL ASS'Y	48	BEARING RETAINER	65	KEYED DRAG WASHER	82	HANDLE NUT CAP
15	SHUTTLE GEAR	32	BUSHING	49	BALL BEARING	66	BUSHING	83	SCREW
16	E-RING	33	SPOOL GEAR	50	BEARING RETAINER	67	BUSHING		
17	CARRIER GUIDE RETAINER	34	E-RING	51	GEAR STEM	68	BUSHING		

AGL200