
ARSENAL

AR15AL
AR20AL



NO.	PART NAME	
1	FRAME ASSM'	
2	L-WIND SUPPORT SHAFT	
3	WORM SHAFT GUIDE	
4	WORM SHAFT	
5	LEVEL WIND ASSM'	
6	LEVEL WIND PAWL	
7	SPACER	1146818
8	LEVEL WIND NUT	
9	W-SHAFT BUSHING(LEFT)	
10	IDLERS	
11	"E" WASHER	1145278
12	W-SHAFT BUSHING(RIGHT)	
13	"E" WASHER	1145278
14	C-RING-B	
15	BALL BEARING	
16	SPOOL ASSM'	
17	CLICK WHEEL	
18	CLICK WHEEL SCREW	
19	LEVEL WIND DRIVE GEAR	
20	C-RING	
21	LEFT COVER	
22	SPOOL SPACER	
23	BUSHING	
24	CLICK METAL	
25	COIL SPRING	1146781
26	CLICK PLATE	
27	CLICK METAL SCREW	
28	CLICK SWITCH	
29	CLICK CLAW	

NO.	PART NAME	
30	WASHER	1146825
31	"E" WASHER	1145283
32	CLICK SPRING	
33	CLICK SPRING SCREW	
34	IDLER GEAR	
35	IDLER GEAR WASHER	1146828
36	"E" WASHER	1145278
37	PROTECTOR-L	
38	PROTECTOR-L SCREW	
39	RIGHT COVER	
40	BEARING SLEEVE	
41	BEARING SLEEVE SCREW	
42	BALL BEARING	1145079
43	ONE WAY CLUTCH	
44	SPRING WASHER	1146895
45	DRIVE WASHER(D)	
46	DRIVE WASHER	
47	EARE WASHER	
48	DRIVE GEAR	
49	AR RATCHET ASSM'	
50	DRIVE SHAFT WASHER	
53	WASHER	1146825
54	CRANK SHAFT	
55	BUSHING	
56	ANTI-REVERSE SPRING	
57	ANTI-REVERSE PAWL	
58	ANTI-REVERSE POST	
59	SET PLATE	

NO.	PART NAME	
60	SET PLATE SCREW	
61	SPACER	1146825
62	RETAINER	1145281
63	PINION YOKE SPRING	
64	PINION GEAR ASSM'	
65	PINION YOKE	
66	CLUTCH SPRING	
67	CLUTCH CAM	
68	CAM PLATE	
69	PLATE SCREW	
70	CLUTCH LEVER	
71	CLUTCH LEVER SCREW	
72	CAST CONTROL SPRING	1146745
73	WASHER	
74	CAST CONTROL CAP	
75	PROTECTOR-R	
76	PROTECTOR-R SCREW	
77	RIGHT COVER SCREW	
78	SPRING WASHER	1146769
80	STAR DRAG	
81	LEAF SPRING	
82	HANDLE ASSM'	
83	HANDLE NUT	1145871
84	NUT RETAINER	
85	NUT RETAINER SCREW	
86	CLUTCH SLEEVE	