


# Shakespeare®

Model GX210

SKP-SC-GX2-10-04



| ITEM | DESCRIPTION     | SAP #   | ITEM | DESCRIPTION   | SAP #   | ITEM | DESCRIPTION     | SAP #   | ITEM | DESCRIPTION | SAP #   |
|------|-----------------|---------|------|---------------|---------|------|-----------------|---------|------|-------------|---------|
| 1    | FRONT COVER ASM | 1322467 | 8    | SPOOL         | 1322471 | 15   | SPRING          | 1322479 | 22   | DRAG KNOB   | 1322474 |
| 2    | PICK UP HOUSING | 1322468 | 9    | WASHER        | 1322487 | 16   | BACK COVER      | 1322482 | 23   | DRAG NUT    | 1322473 |
| 3    | PIN SPRING      | 1322490 | 10   | SPRING WASHER | 1322486 | 17   | BACK COVER DECK | 1322481 | 24   | DRAG SCREW  | 1322472 |
| 4    | PICKUP PIN      | 1322489 | 11   | BODY          | 1322485 | 18   | THUMB BUTTON    | 1322480 |      |             |         |
| 5    | E CLIP          | 1322469 | 12   | A/R CLAW      | 1322478 | 19   | DRIVE GEAR      | 1322477 |      |             |         |
| 6    | E-WASHER        | 1322470 | 13   | CENTER SHAFT  | 1322484 | 20   | HANDLE ASM      | 1322475 |      |             |         |
| 7    | DRAG WASHER     | 1322488 | 14   | PINION        | 1322483 | 21   | HANDLE NUT      | 1322476 |      |             |         |