

MODEL : INT420UL

Rev:01

ITEM	DESCRIPTION	SAP#		ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1207323		32	CLUTCH SPRING	1207344
2	STOP RING	1207324		33	SCREW	1207345
3	KEY WASHER	1205817		34	BEARING COVER	1207346
4	DRAG WASHER	1205818		35	BEARING 14×7×3.5	1207108
5	EARED WASHER	1205879		36	PINION GEAR	1207347
6	SPOOL SUB-ASSY	1207325		37	N-R LEVER SPRING	1207348
6A	COMPLETE SPOOL	1222137		38	N-R LEVER GUIDE	1207349
7	CLICK GEAR WASHER	1200771		39	N-R LEVER SHAFT	1207350
8	CLICK GEAR	1201821		40	SCREW	1207351
9	MAIN SHAFT	1207326		41	N-R LEVER	1207352
10	SCREW	1207327		42	HANDLE LOCK	1207353
11	BAIL HOLDER	1207328		43	H-LOCK WASHER	1207111
12	BAIL WIRE SUB-ASSY	1207329		44	BEARING 11×7×2.5	1207354
13	LINE ROLLER BUSHING	1205948		45	DRIVE GEAR	1207355
14	LINE ROLLER	1205949		46	GEAR WASHER	1200798
15	LINE ROLLER COLLAR	1205950		47	GEAR WASHER	1200876
16	BAIL ARM	1207330		48	BEARING 14×8×3.5	1200865
17	SCREW	1207331		49	BODY COVER ASSY	1207356
18	SCREW	1207332		50	SCREW	1207357
19	ROTOR COVER	1207333		51	HANDLE ASSY	1207358
20	BAIL SPRING	1207334		52	SCREW	1207359
21	BAIL ARM GUIDE	1207335		53	O/S SLIDER	1207360
22	TRIP PLUNGER	1207336		54	O/S GEAR	1207361
23	BAIL HOLDER COVER	1207337		55	SCREW	1207362
24	ROTOR	1222138		56	O/S SLIDER PLATE	1205910
25	SCREW	1207339		57	SCREW	1207363
26	ROTOR NUT RETAINER	1200795		58	REAR COVER	1207364
27	ROTOR NUT	1205892		59	INNER COVER	1207365
28	CLUTCH WASHER	1207340		60	BODY ASSY	1207366
29	SCREW	1207341		61	SCREW	1207592
30	WASHER	1207342		62	COUNTER WEIGHT	1222139
31	ONE WAY CLUTCH	1207343		63	WASHER	1222140

EXPLODED VIEW

