


INT440F

In trepid 440F



NO. PART NAME

1. BODY ASSEMBLY
2. N-R LEVER
3. N-R LEVER SHAFT
4. N-R LEVER SCREW
5. N-R LEVER SPRING
6. PINION BUSHING
7. PINION
8. BALL BEARING—1145073
9. ONE WAY CLUTCH—1145112
10. CLUTCH SPRING—1146736
11. BEARING SLEEVE
12. WASHER
13. BEARING COVER
14. SCREW BEARING COVER
15. WASHER PINION
16. ROTOR ASSEMBLY

17. TRIP PLUNGER
18. BAIL ARM SPRING—1146726
19. BAIL ARM GUIDE—1145733
20. BAIL ARM COVER
21. BAIL ARM COVER SCREW
22. BAIL ARM
23. BAIL ARM SCREW
24. BAIL WIRE ASSEMBLY—1145049
25. BAIL HOLDER
26. LINE ROLLER BUSHING—1146340
27. LINE ROLLER—1146122
28. LINE ROLLER WASHER—1146856
29. L-ROLLER SCREW—1146251
30. ROTOR NUT
31. ROTOR NUT WASHER
32. ROTOR NUT SCREW
33. O/S SLIDER PLATE
34. O/S SLIDER PLATE SCREW
35. BUSHING 12 x 8 x 2.5—1145076
36. O/S GEAR—1145657
37. O/S SLIDER
38. MAIN SHAFT
39. O/S SLIDER SCREW
40. DRIVE GEAR—1145667
41. GEAR WASHER—1146817
42. BODY COVER ASSEMBLY
43. COVER SCREW A—1146271
44. COVER SCREW B

45. CLICK GEAR—1146029
46. SHEET WASHER—1146805
47. SPOOL ASSEMBLY—1146593
48. DRAG WASHER
49. LINING WASHER
50. SPOOL WASHER
51. STOP RING
52. DRAG KNOB—1145902
53. DRAG CLICK SPRING
54. DRAG CLICK PIN
55. DRAG NUT
56. DRAG SPRING
57. DRAG SPRING WASHER
58. DRAG KNOB COVER
59. DRAG KNOB SCREW
60. INNER COVER
62. REAR COVER SCREW
63. HANDLE ARM ASSEMBLY—1145525
64. HANDLE LOCK WASHER
65. HANDLE LOCK ASSEMBLY—1145276
66. BAIL HOLDER WASHER

ReelSchematic