


Shakespeare®



Please specify reel model number and number in reel foot when ordering parts.

SIGMA
SIGMA3BC

23 00

1225975

34-12973-0



ReelSchematic

ITEM#	PART #	DESCRIPTION
1	1306751	LEFT SIDE PLATE
2	1306752	MAG DIAL
3	1134431	CLICK SPRING
4	1306753	CAM CURVE-A
5	1134432	O-RING
6	1306754	CAM CURVE-B
7	1306755	LINE REJECTER
8	1306756	COIL SPRING
9	1306757	MAGNET HOLDER
10	1134438	SCREW
11	1306758	SCREW
12	1306759	SCREW
13	1306760	WASHER
14	1153296	BALL BEARING
15	1134442	LOCK RING
16	1306761	SPOOL
17	1104799	RETAINER
18	1134444	BUSHING
19	1138559	WORM SHAFT TUBE
20	1134453	SCREW
21	1306762	FRONT COVER
22	1134448	LINE GUIDE NUT
23	1306763	WASHER
24	1306764	PAWL
25	1306765	WORM SHAFT
26	1306766	WASHER
27	1134451	GEAR
28	1104799	RETAINER
29	1306767	LINE GUIDE
30	1306768	SCREW
31	1306769	LINE GUIDE SHAFT
32	1306770	SCREW
33	1306771	FRAME
34	1306772	THUMB BAR
35	1134458	BUSHING
36	1306773	CLUTCH CAM SPRING
37	1306774	CLUTCH CAM
38	1134460	SCREW

ITEM#	PART #	DESCRIPTION
39	1306775	KICK LEVER SPRING
40	1306776	KICK LEVER
41	1306777	YOKE
42	1306778	YOKE SPRING
43	1306779	PINION
44	1134465	O-RING
45	1306780	RIGHT SIDE PLATE
46	1306781	THUMB SCREW
47	1306782	O-RING
48	1306783	WASHER
49	1306784	BRAKE KNOB
50	1306795	SCREW
51	1306796	BUSHING
52	1134468	RETAINER
53	1134469	MAIN GEAR SHAFT PLATE
54	1306787	WASHER
55	1134436	SCREW
56	1306786	MAIN GEAR SHAFT
57	1065960	O/S GEAR
58	1134497	WASHER
59	1134471	RATCHET
60	1306789	DRAG WASHER
61	1306790	MAIN GEAR
62	1134473	DRAG WASHER
63	1134474	PRESSURE WASHER
64	1306791	IAR SLEEVE
65	1134475	IAR BEARING
66	1306792	BALL BEARING
67	1134478	WASHER
68	1065971	SPRING WASHER
69	1134497	WASHER
70	1306793	STAR WHEEL
71	1306794	SPRING WASHER
72	1306795	HANDLE
73	1306796	HANDLE NUT
74	1306797	HANDLE NUT COVER
75	1306798	SCREW
76	1308480	CUSHION WASHER