
www.reelschematic.com

TIDEWATER®

Use this parts list for ordering replacement parts for your Tidewater reel. When ordering parts, **please** specify whether you are ordering for the



Part #	Part Name	Part #	Part Name
1	Left Side Plate Assembly	41	Adjust Plate
2	Left Side Plate Cover Assembly	42	Adjust Plate Screw
4	Line Guard	43	Adjust Control Level Assembly
5	Body Support Shaft	45	Adjust Control Level Screw
6	Body Foot	46	2 Bushings (10L/30L)
7	Right Side Plate Cover Screw		1 Bushing & 1 Bearing (10LA/30LA)
8	Click Button	48	Drag Adjust Handle Assembly
9	Click Button Washer	49	Right Side Plate Assembly
10	Click Pawl	50	Right Side Plate Cover Assembly
11	E. Clip 79-15-0019-01	52	Handle Assembly
12	Click Power Spring	55	Handle Nut
13	Click Power Spring Screw	57	Handle Nut Return
14	Shaft Bushing	58	Handle Spring Washer
15	Spool Assembly	60	Tension Knob 79-12-0074-01
19	Ball Bearing (10LA & 30LA Only)	61	Tension Knob Washer 79-72 0721-01
20	Pinion Gear 79-46-0125-01	69	Label
21	Anti-Reverse Pawl Assembly	70	Label
22	Anti-Reverse Bushing	71	Driving Gear 79-28-0228-01
23	Anti-Reverse Spring	72	Medium Gear 79-28-0227-01
24	Spring Washer	75	Line Guide
25	Drag Washer (Square Center)	77	Line Guide Pawl Cap
26	Key Washer	78	Line Guide Pawl 79-43-0141-01
27	Drag Washer 79-72-0717-01	79	Washer 79-72-0691-01
28	Main Gear	80	Line Guard Plate
29	Ratchet Gear Assembly	82	Bushing
30	Ratchet Gear Washer	84	Worm Shaft (Level Wind) 79-60-0186-01
32	Drag Gear Shaft	87	Line Guard Support Shaft
33	Drag Gear Shaft Support Plate	88	Handle Nut Return Screw 7818-46
34	E. Clip 79-19-0050-01	90	Screw
35	Click Washer	91	Screw
36	Drag Gear Shaft Support Screw	93	Screw
37	Clutch Spring 2967-0714-01	101	Screw
38	Clutch	102	Washer 7965-0035-01
39	Adjust Block	103	Bushing Washer
40	Adjust Block Spring	104	o Ring 79-54-0134 01

Tension Knob Assemb 79-80-0001 01