
www.reelschematic.com

TIDEWATER®

Use this parts list for ordering replacement parts for your Tidewater reel. When ordering parts, please specify whether you are ordering for the



Part #	Part Name
1	Left Side Plate Assembly
2	Left Side Plate Cover Assembly
4	Line Guard
5	Body Support Shaft
6	Body Foot
7	Right Side Plate Cover Screw
8	Click Button
9	Click Button Washer
10	Click Pawl
11	E. Clip 79-15-0019-01
12	Click Power Spring
13	Click Power Spring Screw
14	Shaft Bushing
15	Spool Assembly 30L-104
19	Ball Bearing (10LA & 30LA Only)
20	Pinion Gear 79-46-0125-01
21	Anti-Reverse Pawl Assembly
22	Anti-Reverse Bushing
23	Anti-Reverse Spring
24	Spring Washer
25	Drag Washer (Square Center)
26	Key Washer
27	Drag Washer 79-72-0717-01
28	Main Gear
29	Ratchet Gear Assembly
30	Ratchet Gear Washer
32	Drag Gear Shaft
33	Drag Gear Shaft Support Plate
34	E. Clip 79-19-0050-01
35	Click Washer
36	Drag Gear Shaft Support Screw
37	Clutch Spring 7967-0714-01
38	Clutch
39	Adjust Block
40	Adjust Block Spring

Part #	Part Name
41	Adjust Plate
42	Adjust Plate Screw
43	Adjust Control Level Assembly
45	Adjust Control Level Screw
46	2 Bushings (10L/30L) 1 Bushing & 1 Bearing (10LA/30LA)
48	Drag Adjust Handle Assembly
49	Right Side Plate Assembly
50	Right Side Plate Cover Assembly
52	Handle Assembly
55	Handle Nut
57	Handle Nut Return
58	Handle Spring Washer
60	Tension Knob 79-12-0074-01
61	Tension Knob Washer 79-72 0721-01
69	Label
70	Label
71	Driving Gear 79-28-0228-01
72	Medium Gear 79-28-0227-01
75	Line Guide
77	Line Guide Pawl Cap
78	Line Guide Pawl 79-43-0141-01
79	Washer 79-72-0691-01
80	Line Guard Plate
82	Bushing
84	Worm Shaft (Level Wind) 79-60-0187-01
87	Line Guard Support Shaft
88	Handle Nut Return Screw 7818-46
90	Screw
91	Screw
93	Screw
101	Screw
102	Washer 7965-0035-01
103	Bushing Washer
104	o Ring 79-54-0134 01

Tension Knob Assembly 79-80-0001 01