


TIDEWATER®

Use this parts list for ordering replacement parts for your Tidewater reel. When ordering parts, please specify whether you are ordering for the



Part #	Part Name	Part #	Part Name
1	Left Side Plate Assembly	41	Adjust Plate
2	Left Side Plate Cover Assembly	42	Adjust Plate Screw
4	Line Guard	43	Adjust Control Level Assembly
5	Body Support Shaft	45	Adjust Control Level Screw
6	Body Foot	46	2 Bushings (10L/30L)
7	Right Side Plate Cover Screw		1 Bushing & 1 Bearing (10LA/30LA)
8	Click Button	48	Drag Adjust Handle Assembly
9	Click Button Washer	49	Right Side Plate Assembly
10	Click Pawl	50	Right Side Plate Cover Assembly
11	E. Clip <u>79-15-0019-01</u>	52	Handle Assembly
12	Click Power Spring	55	Handle Nut
13	Click Power Spring Screw	57	Handle Nut Return
14	Shaft Bushing	58	Handle Spring Washer
15	Spool Assembly <u>30L-10L</u>	60	Tension Knob <u>79-12-0074-01</u>
19	Ball Bearing (10LA & 30LA Only)	61	Tension Knob Washer <u>79-72-0731-01</u>
20	Pinion Gear <u>79-46-0125-01</u>	69	Label
21	Anti-Reverse Pawl Assembly	70	Label
22	Anti-Reverse Bushing	71	Driving Gear <u>79-28-0228-01</u>
23	Anti-Reverse Spring	72	Medium Gear <u>79-28-0227-01</u>
24	Spring Washer	75	Line Guide
25	Drag Washer (Square Center)	77	Line Guide Pawl Cap
26	Key Washer	78	Line Guide Pawl <u>79-43-0141-01</u>
27	Drag Washer <u>79-72-0717-01</u>	79	Washer <u>79-72-0691-01</u>
28	Main Gear	80	Line Guard Plate
29	Ratchet Gear Assembly	82	Bushing
30	Ratchet Gear Washer	84	Worm Shaft (Level Wind) <u>79-60-0187-01</u>
32	Drag Gear Shaft	87	Line Guard Support Shaft
33	Drag Gear Shaft Support Plate	88	Handle Nut Return Screw <u>7818-46</u>
34	E. Clip <u>79-19-0050-01</u>	90	Screw
35	Click Washer	91	Screw
36	Drag Gear Shaft Support Screw	93	Screw
37	Clutch Spring <u>79-67-0714-01</u>	101	Screw
38	Clutch	102	Washer <u>7965-0035-01</u>
39	Adjust Block	103	Bushing Washer
40	Adjust Block Spring	104	2 Ring <u>79-54-0134-01</u>

Tension Knob Assembly 79-80-0001-01