



| Part # | Part Name           | Part #        | Part Name |
|--------|---------------------|---------------|-----------|
| 1      | Frame               | 79-27-0194-01 |           |
| 2      | Clutch Bar Pin      | 79-45-0047-01 |           |
| 3      | Clutch Bar          | 79-37-0217-01 |           |
| 4      | Washer              | 79-72-0698-01 |           |
| 5      | Retainer (2.5)      | 63-205-901    |           |
| 8      | Spacer A            | 79-65-0031-01 |           |
| 9      | Ball Bearing        | 79-04-0100-01 |           |
| 10     | Bearing Retainer    | 6K-170-701    |           |
| 11     | Pillar              | 79-44-0020-01 |           |
| 12     | Level Wind          | 79-05-0025-01 |           |
| 13     | Retainer (2.0)      | 6B-339-801-01 |           |
| 14     | Level Wind Guard    | 79-30-0010-01 |           |
| 15     | Worm Shaft Bush     | 79-09-0048-01 |           |
| 16     | Worm Shaft          | 79-60-0165-01 |           |
| 17     | Worm Shaft Bush A   | 79-09-0049-01 |           |
| 18     | Washer              | 79-72-0698-01 |           |
| 19     | Retainer (2.5)      | 63-205-901    |           |
| 20     | Line Guide Pawl     | 79-43-0135-01 |           |
| 21     | Line Guide Was      | 79-72-0691-01 |           |
| 22     | Level Wind Nut      | 79-40-0331-01 |           |
| 23     | Left Side Cover     | 79-19-0110-01 |           |
| 24     | Left Side Cover S.  | 79-58-0706-01 |           |
| 25     | Spool               | 79-66-0270-01 |           |
| 26     | Brake Collar        | 79-17-0019-01 |           |
| 27     | Set Plate           | 79-47-0468-01 |           |
| 28     | Idle Gear           | 79-28-0205-01 |           |
| 29     | Washer              | 79-72-0698-01 |           |
| 30     | Idle Gear Screw     | 79-58-0705-01 |           |
| 31     | Clutch Cam          | 79-11-0067-01 |           |
| 32     | Kick Lever          | 79-37-0223-01 |           |
| 33     | Kick Lever Spring   | 79-67-0691-01 |           |
| 34     | Cam Plate           | 79-47-0470-01 |           |
| 35     | Cam Plate Screw     | 79-58-0705-01 |           |
| 36     | Spring Collar       | 79-17-0020-01 |           |
| 37     | Clutch Spring Cam   | 79-67-0694-01 |           |
| 38     | Pinion Gear         | 79-46-0114-01 |           |
| 39     | Yoke                | 79-75-0075-01 |           |
| 40     | Yoke Spring         | 79-67-0205-01 |           |
| 41     | Retainer            | 79-15-0051-01 |           |
| 42     | Crank Shaft Wash    | 79-72-0699-01 |           |
| 43     | Ball Bearing        | 79-04-0101-01 |           |
| 44     | O/S Gear Washer     | 79-72-0700-01 |           |
| 45     | O/S Gear            | 79-28-0210-01 |           |
| 46     | Crank Shaft         | 79-60-0171-01 |           |
| 47     | Kicking Ratchet     | 79-50-0071-01 |           |
| 48     | Drag Washer A       | 79-72-0692-01 |           |
| 49     | Drive Gear          | 79-28-0209-01 |           |
| 50     | Drag Washer B       | 79-72-0697-01 |           |
| 51     | Key Washer          | 79-72-0696-01 |           |
| 52     | Right Side Cover    | 79-19-0111-01 |           |
| 53     | Thumb Screw Wash    | 79-72-0701-01 |           |
| 54     | Thumb Screw         | 79-58-0707-01 |           |
| 55     | Thumb Screw Ring    | 79-54-0133-01 |           |
| 56     | Oiless Bearing      | 79-04-0089-01 |           |
| 57     | Crank Shaft Plate   | 79-47-0469-01 |           |
| 58     | O-Ring              | 79-54-0132-01 |           |
| 59     | Spacer B            | 79-65-0027-01 |           |
| 60     | Cushion Washer      | 79-72-0693-01 |           |
| 61     | Cast Control Cap    | 79-12-0065-01 |           |
| 62     | Right Side Cover Sc | 79-58-0704-01 |           |
| 63     | One Way Bearing     | 79-04-0090-01 |           |
| 64     | Sleeve              | 79-63-0035-01 |           |
| 65     | Drag Spring Washer  | 6K-160-702    |           |
| 66     | Star Drag           | 79-79-0013-01 |           |
| 67     | Friction Washer     | 6K-161-401    |           |
| 68     | Handle              | 79-20-0173-01 |           |
| 69     | Handle Nut          | 79-40-0332-01 |           |
| 70     | Handle Nut Cap      | 79-12-0066-01 |           |
| 71     | Handle Nut Cap Sc   | 79-58-0700-01 |           |
| 72     | Ball Bearing        | 79-04-0102-01 |           |
| 73     | Bearing Retainer    | 79-53-0073-01 |           |