



() Indicates Old Style
 * Indicates New Style

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
001	79-66-0067-01	Spool Assembly	30	79-47-0122-01	Trip Lever Plate
1	79-40-0067-01	Drag Nut	31	79-58-0121-01	Plate Screw
2	79-53-0033-01	Retainer	32	Not Available	Pickup Housing
3	79-72-0233-01	Metal Washer	33	79-58-0160-01	Stop Screw
4	79-72-0234-01	Fiber Washer	34	79-58-0016-01	Retainer Screw
5	79-72-0235-01	Eared Washer	35	79-53-0034-01	Bearing Retainer
6	79-72-0234-01	Fiber Washer	36	79-04-0010-01	Ball Bearing
7	79-72-0233-01	Metal Washer	37	79-63-0020-01	Sleeve
8	79-72-0234-01	Fiber Washer	38	79-50-0018-01	Ratchet
(10)	79-67-0086-01	Click Spring	39	79-46-0035-01	Pinion
11	79-71-0002-01	Click Spring Stud	40	79-58-0123-01	Non-Reverse Screw
12	79-72-0220-01	Rear Washer	41	79-67-0087-01	Non-Reverse Spring
13	79-60-0045-01	Main Shaft	42	79-37-0027-01	Non-Reverse Lever
14	79-03-0041-01	Bail Wire	43	Not Available	Frame Assembly
15	79-58-0119-01	Bail Screw	44	79-20-0017-01	Throwout Arm
16	79-51-0010-01	Line Roller	45	79-10-0017-01	Non-Reverse Button
17	79-21-0006-01	Spacer	(46)	79-54-0028-01	Retainer Clip
18	79-72-0183-01	Washer	47	79-12-0014-01	Frame Cap
19	79-40-0050-01	Roller Nut	48	79-37-0044-01	Level Wind Lever
20	79-07-0029-01	Bail Bracket	49	79-28-0048-01	Drive Gear
21	79-58-0119-01	Bail Bracket Screw	50	79-20-0064-01	Crank Assembly
22	79-67-0088-01	Bail Spring	51	79-47-0120-01	Cover Plate
23	79-47-0121-01	Bail Spring Plate	52	79-58-0125-01	Cover Plate Screw
24	79-58-0121-01	Plate Screw	(53)	79-72-0187-01	Drive Gear Washer
25	79-40-0068-01	Pickup Nut	*53	79-67-0151-01	Click Spring
26	79-72-0236-01	Pickup Washer	(54)	79-72-0237-01	Bearing Thrust Washer
27	79-62-0089-01	Trip Lever Spring	*54	79-72-0187-01	Drive Gear Washer
28	79-37-0045-01	Trip Lever	55	79-53-0046-01	Retainer Clip
29	79-58-0161-01	Trip Lever Screw			