



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
001	79-66-0063-01	Spool Assembly	26	79-67-0059-01	Trip Lever Spring
1	79-40-0049-01	Drag Nut	27	79-40-0051-01	Pickup Nut
2	79-53-0023-01	Retainer	29	79-58-0121-01	Plate Screw
3	79-72-0121-01	Washer	30	79-47-0080-01	Plate
4	79-72-0181-01	Drag Washer	31	Not Available	Pickup Housing
5	79-72-0129-01	Eared Washer	32B	79-04-0038-01	Ball Bearing
6	79-72-0181-01	Drag Washer	33	79-63-0014-01	Sleeve
9	79-43-0083-01	Click Pawl	34	79-46-0025-01	Pinion
10	79-58-0262-01	Click Pawl Screw	35	79-58-0123-01	Non Reverse Lever Screw
11	79-72-0150-01	Washer	37B	Not Available	Frame
12	79-60-0031-01	Main Shaft	38	79-02-0015-01	Throwout Arm
13B	79-58-0263-01	Bail Screw	39	79-10-0017-01	Non Reverse Button
14B	79-33-0002-01	Bail Wire Holder	40	79-50-0013-01	Ratchet
15B	79-03-0048-01	Bail Wire	41	79-12-0014-01	Crank Cap
16	79-57-0010-01	Line Roller	43	79-37-0028-01	Level Wind Lever
17	79-21-0009-01	Spacer Cup	44	79-28-0067-01	Drive Gear
18	79-72-0359-01	Washer	46	79-20-0074-01	Crank
19B	79-07-0041-01	Bail Bracket	47	79-47-0198-01	Cover Plate
20B	79-58-0264-01	Bail Bracket Screw	48	79-58-0125-01	Cover Plate Screws
21	79-58-0265-01	Roller Screw	54	79-45-0020-01	Pin for Throwout Arm
22	79-58-0122-01	Plate Screw	55	79-67-0148-01	Click Spring
24	79-67-0048-01	Bail Spring	56	79-67-0061-01	Non-Reverse Spring
25	79-37-0025-01	Trip Lever	59	79-37-0027-01	Non-Reverse Lever