



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
001	79-66-0075-01	Spool Assembly	42	79-46-0031-01	Pinion
1	79-40-0059-01	Drag Nut	43	N/A	Frame Assembly
2	79-54-0001-01	Retainer Ring	44	79-58-0150-01	Cover Plate Screw
3	79-72-0121-01	Metal Washer	45	79-47-0097-01	Cover Plate
4	79-72-0315-01	Fiber Washer	50	79-28-0075-01	Drive Gear
5	79-72-0129-01	Eared Washer	51	79-58-0012-01	Non-Reverse Pawl Screw
7	79-43-0002-01	Click Pawl	52	79-54-0002-01	Non-Reverse Button Retainer
8	79-58-0001-01	Click Pawl Screw	53	79-43-0064-01	Non-Reverse Pawl
9	79-72-0316-01	Rear Washer	57	79-67-0077-01	Non-Reverse Pawl Spring
10	79-72-0150-01	Rear Washer	60	79-10-0019-01	Non-Reverse Button
11	79-60-0039-01	Main Shaft	63	79-20-0058-01	Crank Assembly
12	79-03-0034-01	Bail Wire Assembly	65	79-67-0003-01	Click Pawl Spring
13	79-40-0060-01	Pickup Nut	67	79-00-0001-01	Bail Stop
14	79-72-0222-01	Pickup Washer	69	79-63-0001-01	Roller Sleeve
15	N/A	Pickup Housing	70	79-21-0001-01	Spacer Cup
16	79-58-0147-01	Bail Screw	71	79-08-0007-01	Bail Brake
17	79-58-0062-01	Trip Lever Screw	73	79-50-0042-01	Ratchet
18	79-37-0039-01	Trip Lever	76	79-02-0008-01	Throwout Arm
19	79-67-0039-01	Trip Lever Spring	85	79-67-0004-01	Bail Stop Spring
22	79-57-0001-01	Line Roller	88	79-12-0008-01	Crank Cap
23	79-07-0025-01	Bail Bracket	91	79-37-0038-01	Level Wind Lever
24	79-58-0147-01	Bail Bracket Screw	92	79-58-0149-01	Bail Spring Plate Screw
25	79-67-0042-01	Bail Spring	95	79-47-0098-01	Bail Spring Plate
29	79-58-0050-01	Roller Screw	106	79-47-0096-01	Trip Lever Plate
39	79-58-0032-01	Bearing Retainer Screw	107	79-58-0143-01	Trip Lever Plate Screw
40	79-53-0030-01	Bearing Retainer	112	79-11-0020-01	Silent Anti-Reverse Cam
41	79-04-0027-01	Ball Bearing			