


*Shakespeare*

SINCE 1897



REF #	PART NUMBER	DESCRIPTION	REF #	PART NUMBER	DESCRIPTION
001	79-86-0252-01	SPOOL ASSEMBLY	1	79-40-0336-01	DRAG NUT
2	79-54-0128-01	RETAINER RING	3	79-72-0658-01	METAL WASHER
4	79-72-0659-01	FIBER WASHER	5	79-72-0660-01	EARED WASHER
7	79-43-0126-01	CLICK PAWL	8	79-58-0640-01	CLICK PAWL SCREW
10	79-72-0665-01	REAR WASHER	11	79-60-0152-01	MAIN SHAFT
12	79-03-0124-01	BAIL WIRE	13	79-40-0209-01	PICKUP NUT
14	79-72-0668-01	PICKUP WASHER	15	79-34-0149-01	PICKUP HOUSING
16	79-58-0648-01	BAIL SCREW	17	79-58-0645-01	TRIP LEVER SCREW
18	79-37-0201-01	TRIP LEVER	19	79-67-0657-01	TRIP LEVER SPRING
22	79-57-0052-01	LINE ROLLER	23	79-07-0088-01	BAIL BRACKET
24	79-58-0648-01	BRACKET SCREW	25	79-67-0661-01	BAIL SPRING
29	79-58-0651-01	ROLLER SCREW	39	79-58-0653-01	BEARING RETAINER SCREW
40	79-53-0065-01	BEARING RETAINER	41	79-04-0081-01	BALL BEARING
42	79-46-0104-01	PINION	43	79-27-0177-01	FRAME
44	79-58-0656-01	COVER PLATE SCREW	45	79-47-0413-01	COVER PLATE
46	79-75-0070-01	LEVEL WIND YOKE	48	79-58-0658-01	YOKE SCREW
50	79-28-0186-01	DRIVE GEAR	51	79-58-0660-01	N/R PAWL SCREW
52	79-15-0055-01	E-CLIP	53	79-43-0130-01	N/R PAWL
57	79-67-0667-01	N/R PAWL SPRING	60	79-10-0086-01	N/R BUTTON
63	79-20-0157-01	CRANK ASSEMBLY	65	79-67-0669-01	CLICK SPRING
70	79-21-0042-01	ROLLER CUP	71	79-00-0033-01	BAIL STOP
72	79-63-0031-01	SLEEVE	73	79-50-0065-01	RATCHET
76	79-02-0035-01	THROWOUT ARM	88	79-12-0061-01	CRANK CAP
92	79-58-0664-01	BAIL SPRING P/SCREW	95	79-47-0419-01	BAIL SPRING PLATE
98	79-28-0022-01	OSCILLATION GEAR	100	79-58-0668-01	GEAR SCREW
106	79-47-0424-01	TRIP LEVER PLATE	107	79-58-0428-01	TRIP LEVER P/SCREW
112	79-11-0061-01	CAM	114	79-57-000801	WEAR BUSHING
115	7972068701	WASHER			

REVISED 6-13-96 REF# 2 16 98 AND 114

REVISED 7-28-97 REF# 1 79-40-0336-01