



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	79-40-0048-01	Drag nut	70	79-21-0010-01	Line Roller Cup
3	79-72-0242-01	Metal Washer	71	79-08-0016-01	Bail Brake
5	79-72-0243-01	Eared Washer	73	79-50-0048-01	Ratchet
7	79-67-0157-01	Click Spring	76	79-02-0029-01	Throwout Arm
8	79-58-0275-01	Click Screw	87	79-04-0016-01	Ball Bearing
11	79-60-0107-01	Main Shaft	88	79-12-0008-01	Crank Cap
12	79-03-0080-01	Bail Wire	91	79-37-0078-01	Level Wind Lever
13	79-40-0001-01	Pickup Nut	92	79-58-0279-01	Plate Screw
14	79-72-0246-01	Pickup Nut Washer	95	79-47-0257-01	Bail Spring Plate
15	42/30-15	Pickup Housing	106	79-47-0258-01	Trip Lever Plate
16	79-58-0478-01	Bail Screw	107	79-58-0247-01	Plate Screw
17	79-58-0270-01	Trip Lever Screw	108	79-58-0276-01	Trip Spring Screw
18	79-37-0079-01	Trip Lever	112	79-11-0035-01	Silent N/R Cam
19	79-67-0037-01	Trip Lever Spring	115	79-02-0028-01	Silent A/R Arm
22	79-57-0007-01	Line Roller	123	79-61-0002-01	Drag Shaft
23	79-07-0062-01	Bail Bracket	124	79-72-0245-01	Vinyl Washer
24	79-58-0479-01	Bail Bracket Screw	125	79-72-0241-01	Latch Washer
25	79-67-0270-01	Bail Spring	126	79-72-0244-01	Fiber Washer
29	79-58-0280-01	Roller Screw	127	79-72-0240-01	Metal Washer
39	79-58-0277-01	Retainer Screw	128	79-72-0239-01	Nylon Washer
40	79-53-0047-04	Bearing Retainer	129	79-50-0029-01	Drag Ratchet
41	79-04-0001-01	Ball Bearing	130	79-58-0163-01	Drag Knob Screw
42	79-46-0063-01	Pinion	131	79-37-0085-01	Lever
43	42/30-43	Frame Assembly	132	79-45-0021-01	Lever Pin
44	79-58-0273-01	Cover Screw	135	79-67-0091-01	Drag Spring
45	42/30-45	Cover Plate	138	79-65-0008-01	N/R Cam Spacer
46	79-75-0047-01	Level Wind Yoke	144	79-09-0010-01	Trip Lever Bushing
48	79-15-0023-01	Retainer Clip	145	79-65-0006-01	Trip Lever Spacer
50	79-28-0098-01	Drive Gear	147	79-63-0026-01	Threaded Sleeves
51	79-58-0276-01	N/R Pawl Screw	150	79-65-0009-01	N/R Pawl Spacer
52	79-15-0022-01	Retainer Clip	152	79-49-0001-01	Housing Protector
53	79-43-0084-01	A/R Pawl	153	79-15-0020-01	Level Wind Ret. Clip
54	79-67-0163-01	A/R Cam Spring	164	79-28-0112-01	Gear
55	79-11-0033-01	A/R Cam	166	79-47-0220-01	Plate
56	79-72-0365-01	A/R Cam Washer	168	79-37-0105-01	Lever
57	79-67-0152-01	N/R Spring	169	79-58-0349-01	Screw
60	79-60-0069-01	A/R Shaft	170	79-67-0197-01	Spring
63	42/30-63	Crank Assembly	001	42/30-001	Spool Assembly
69	79-63-0010-01	Line Roller Sleeve			