
SHIMANO

ANTARES

# ANT-L




(51RH741000U)

| # | Part No. | Description | # | Part No. | Description | # | Part No. | Description | |
|---|---|---|---|---|---|---|---|---|---|
| 15 | 10D60 | Drag Spring Washer | 4034 | 108Q2 | Anti-Thrust Washer | 4733 | 10LVD | Screw | |
| 32 | 10GEW | Bearing Retainer | 4036 | 10FFW | Line Guide Pawl | 4734 | 10LVL | Screw | |
| 60 | 10CFW | Spacer | 4116 | 103E9 | Screw | 4735 | 104SR | Worm Bushing B | |
| 623 | 103C0 | Screw | 4187 | 104VX | Ball Bearing | 4737 | 10L7Q | Spool Assembly | |
| 664 | 1057S | Spacer B | 4194 | 105BP | Ball Bearing | 4738 | 1046M | Brake Shoe M | |
| 686 | 105NK | E Lock | 4316 | 10MT2 | Screw | 4739 | 10EXU | Brake Ring Gear | |
| 1302 | 103N8 | Screw | 4389 | 104BU | Yoke Spring | 4740 | 10LVA | Screw | |
| 1671 | 10BHX | Washer | 4416 | 10471 | Yoke | 4742 | 104N6 | Washer | |
| 1672 | 105NC | E Lock | 4417 | 10KSC | Clutch Cam | 4744 | 108F1 | Brake Case Washer | |
| 1696 | 10896 | Cast Control Spacer | 4431 | 10G8G | Washer | 4745 | 10A6M | Screw | |
| 2120 | 10KXV | Click Plate Retainer | 4613 | 10AVV | Handle Knob Seal | 4747 | 10BGN | Br Dial Gear | |
| 2122 | 10BT0 | Click Pin | 4661 | 1032A | Handle Knob | 4748 | 10CLG | Idle Gear | |
| 2123 | 10BT2 | Click Spring | 4672 | 105ZV | Clutch Pawl | 4758 | 10FFJ | Handle Nut | |
| 2127 | 10J1N | Star Drag Spacer | 4693 | 10Q5W | Handle Nut Plate | 4759 | 10CFH | Handle Assembly | |
| 2128 | 105PW | Bearing Washer | 4695 | 109VL | Handle Knob Pipe | 4760 | 10AXA | Star Drag | |
| 2144 | 10C47 | Washer | 4696 | 109VE | Handle Shank Assembly | 4761 | 10A0C | Star Drag Nut | |
| 2253 | 103N4 | Screw | 4699 | 10A71 | Star Drag Spring | 4762 | 10K0B | Clutch Button Attachment | |
| 2717 | 105NB | E Lock | 4702 | 10KFU | Cast Control Cap | 4763 | 10J38 | Left Side Plate | |
| 2819 | 10HHN | Washer | 4703 | 10C5Z | Retainer Sheet | 4764 | 10CR9 | Drive Gear | |
| 3036 | 10NJH | Level Wind Guard | 4704 | 10L2F | Cast Control Click Plate | 4765 | 105CY | Drive Shaft | |
| 3076 | 108W8 | O Ring | 4705 | 10L6Y | Cast Control Click Holder | 4766 | 10CU6 | Pinion Gear | |
| 3217 | 10J77 | Idle Gear | 4706 | 10HWE | Cast Control Cap Assembly | 4767 | 10QLQ | Clutch Plate | |
| 3219 | 10FP4 | Idle Gear | 4707 | 10EYU | Bearing Spacer | 4768 | 10BVY | Clutch Guard | |
| 3481 | 10LN7 | Drag Washer | 4708 | 10KNE | Damper Spring | 4769 | 1099C | Clutch Bar Guide B | |
| 3548 | 10CHZ | Drag Washer | 4710 | 10BN1 | Roller Clutch Inner Tube | 4770 | 10MXX | Quick-Fire Ii Clutch Bar | |
| 3577 | 10N1V | Clutch Pawl Spring | 4713 | 109T5 | Drive Shaft Retainer | 4771 | 10QH2 | Level Wind Protector | |
| 3623 | 10CCX | Cast Control Cap Retainer | 4714 | 104JZ | Ball Bearing | 4772 | 104N8 | Thumb Rest | |
| 3627 | 105C0 | Ball Bearing | 4715 | 10NCZ | Worm Bushing A | 4773 | 10JNS | One-Piece Frame | |
| 3744 | 10LVH | Screw | 4716 | 104ZN | Worm Shaft | 4774 | 10FXY | Brake Case | |
| 3748 | 10MPR | Screw | 4717 | 10QSL | Stabilizer Bar | 4775 | 10BBX | Side Plate Cam Lever | |
| 3814 | 10D3M | Key Washer | 4719 | 10F43 | Clutch Cam Retainer | 4776 | 10B22 | Br Dial | |
| 3816 | 10D77 | Anti-Reverse Ratchet | 4720 | 1048C | Clutch Pawl Bushing | 4777 | 10HU5 | Right Side Plate | |
| 3825 | 10LUY | Screw | 4723 | 103CG | Screw | 5021 | 10F33 | Roller Clutch Bearing | |
| 3918 | 10G84 | Washer | 4726 | 10MT8 | Screw | 5860 | 10J26 | Star Drag Click | |
| 3927 | 10EX8 | Ball Bearing | 4728 | 10FJD | Pawl Cap | | | | |
| 3936 | 10B51 | Click Spring | 4729 | 108WQ | O Ring | 3660 | 10MDK | Reel Wrench | (Accessory) |
| 3937 | 10B4Z | Click Pin | 4730 | 10NYQ | Line Guide | 4692 | 10LQ0 | B-100 Oil | (Accessory) |
| 4033 | 108SK | Washer | 4731 | 10CFV | Spacer | 4750 | 1046N | Brake Shoe S | (Accessory) |

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(241120)_004