



AX1000RA 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	1504	Bail Spring Cover Screw	3747	Slider Retainer Screw
0041	Drive Gear Washer	1506	Bail Trip Lever Screw	4051	Bail Spring
0071	Rotor Nut	1596	Bushing Washer	4089	Bail Trip Lever
0080	Line Roller	1695	Drag Knob Screw	4093	Anti-Reverse Cam
0111	Drag Coil Spring	1888	Anti-Reverse Lock Out Spring	4096	Drag Shaft
0345	Anti-Reverse Lever Screw	2257	Drag Washer "H" (blue)	4097	Pressure Screw
0452	Drag Spring Washer	2280	Anti-Reverse Lock Out	4107	Rotor Assembly
0540	Drag Click Screw	2283	Anti-Reverse Pawl Screw	4109	Bail Spring Cover
0543	Side Cover Screw	2293	Drive Gear Bushing	4110	Counterbalance Cover
0574	Drag Washer "C" (cloth)	2852	Handle Screw Lock	4111	Pinion Gear
0579	Eared Washer "B"	3471	Anti-Reverse Cam Spring	4112	Drive Gear
0584	Hold Click Spring	3651	Bail Spring Guide (A)	4113	Drag Knob Assembly
0787	Nut Lock Screw	3652	Bail Spring Guide (B)	4286	Main Shaft Assembly
0792	Bearing Retainer Screw	3655	Cover Screw	4348	Quick-Fire II Trigger
0815	Line Roller Washer	3656	Anti-Reverse Ratchet	4379	Anti-Reverse Lever
0940	Multi-Purpose Screw	3658	Anti-Reverse Pawl	6853	Spool Assembly
0949	Trigger Screw	3659	Anti-Reverse Pawl Spring	6854	Bail Arm
1008	Handle Lock Washer	3663	Oscillating Gear	6875	Bail Assembly
1025	Handle Assembly	3744	Drag Click	6876	Side Cover
1310	Line Roller Screw	3745	Oscillating Slider	6877	Body
1442	Handle Screw Cap	3746	Oscillating Slider Retainer		