



# SHIMANO

## 1989 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

## EXPLODED PARTS VIEW

GRAPHITE CONSTRUCTION
**BAITRUNNER**
*150*



## PARTS LIST

| PART # | DESCRIPTION |
|---|---|
| BR 0010 | Rotor Nut |
| BR 0011 | Nut Lock Screw |
| BR 0014 | Bail Trip Slide Cam |
| BR 0021 | Line Roller |
| BR 0035 | Bearing Retainer Screw |
| BR 0037 | Ball Bearing |
| BR 0045 | Anti-Reverse Lever |
| BR 0046 | Anti-Reverse Lever Screw |
| BR 0047 | Ball Bearing |
| BR 0049 | Drive Gear Washer |
| BR 0057 | Clutch Plate Screw |
| BR 0065 | Dial Click Screw |
| BR 0080 | Side Cover Screw B |
| BR 0092 | Baitrunner Lever Screw |
| BR 0240 | Bail Trip Cover Screw |
| BR 0268 | Drag Knob |
| BR 0269 | Drag Washers Retainer |
| BR 0270 | Key Washer |
| BR 0271 | Drag Washer 1 |
| BR 0272 | Eared Washer |
| BR 0273 | Drag Washer 2 |
| BR 0274 | Drag Spring |
| BR 0275 | Spool Assembly |
| BR 0277 | Spool Washer |
| BR 0278 | Nut Lock Screw |
| BR 0279 | Rotor |
| BR 0280 | Bail Trip Lever |
| BR 0281 | Lever Spring |
| BR 0282 | Bail Trip Cover |
| BR 0283 | Bail Assembly |
| BR 0284 | Bail Trip Cam Screw |

| PART # | DESCRIPTION |
|---|---|
| BR 0285 | Line Roller Washer |
| BR 0286 | Bail Spring Cover |
| BR 0287 | Trigger Screw |
| BR 0288 | Quick-Fire II Trigger |
| BR 0289 | Bail Arm |
| BR 0290 | Bail Spring Guide B |
| BR 0291 | Bail Spring |
| BR 0292 | Bail Spring Guide A |
| BR 0293 | Anti-Reverse Pawl Spring |
| BR 0294 | Anti-Reverse Ratchet |
| BR 0295 | Pinion Gear |
| BR 0296 | Anti-Reverse Pawl Screw |
| BR 0297 | Anti-Reverse Pawl |
| BR 0298 | Anti-Reverse Cam Spring |
| BR 0299 | Anti-Reverse Cam |
| BR 0300 | Body |
| BR 0301 | Bushing |
| BR 0302 | Drive Gear |
| BR 0303 | "C" Lock |
| BR 0304 | Baitrunner Ratchet |
| BR 0305 | Ratchet Spacer |
| BR 0306 | Clutch Spring |
| BR 0307 | Baitrunner Pawl Guide |
| BR 0309 | Clutch Pawl Spring |
| BR 0310 | Side Cover |
| BR 0311 | Lock Washer Retainer |
| BR 0312 | Handle Lock Washer |
| BR 0313 | Handle Screw Cap |
| BR 0314 | Dial Click |
| BR 0316 | Baitrunner Pawl Spring |
| BR 0317 | Baitrunner Pawl |

| PART # | DESCRIPTION |
|---|---|
| BR 0318 | Dial Retainer |
| BR 0319 | Oscillating Gear |
| BR 0320 | Oscillating Slider |
| BR 0321 | Oscillating Slider Retainer |
| BR 0323 | Clutch Cam |
| BR 0324 | Clutch Cam Spacer |
| BR 0325 | Clutch Arm |
| BR 0326 | Lever Shaft Retainer |
| BR 0327 | Clutch Plate Assembly |
| BR 0329 | Baitrunner Lever Arm (L) |
| BR 0330 | Free Spool Tension Shaft |
| BR 0332 | Click Gear |
| BR 0333 | Eared Washer "BFS" |
| BR 0334 | Free Spool Tension Spring |
| BR 0335 | Free Spool Tension Screw |
| BR 0336 | Dial Spacer |
| BR 0337 | Baitrunner Tension Dial |
| BR 0338 | Baitrunner Lever Arm (R) |
| BR 0339 | Baitrunner Lever Bridge |
| BR 0340 | Handle Knob Screw |
| BR 0341 | Handle Knob |
| BR 0342 | Handle Assembly |
| BR 0434A | Main Shaft |
| BR 0435A | Spool Support |
| BR 0652 | Line Roller Screw |
| BR 0655 | Free Spool Tension Washer (A) |
| BR 0656 | Free Spool Tension Washer (B) |
| BR 0685 | Slider Retainer Screw |
| BR 0718 | Baitrunner Click Spring |
| BR 0719 | Adjusting Spacer |

Prices and specifications subject to change without notice.

OCTOBER, 1988