



TO ORDER: USE RD PREFIX  
WITH PART NUMBER

### PARTS LIST

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0012	Shaft Retainer	1008	Handle Lock Washer	2956	BaitRunner Ratchet
0026	Ball Bearing	1023	Handle Screw Cap	2957	Ratchet Spacer
0041	Drive Gear Washer	1067	Key Washer	2958	Clutch Spring
0071	Rotor Nut	1070	Drag Washer 2	2959	Lever Shaft Retainer
0013	Tension Spring Washer "B"	1076	Bail Spring Cover	2960	Clutch Pawl Spring
0132	Anti-Reverse Pawl	1077	Bail Trip Cover	2961	Side Cover
0136	Anti-Reverse Cam Spring	1676	Side Cover Screw(A)	2962	BaitRunner Lever Arm (L)
0163	Spool Washer	1860	Handle Assembly	2963	BaitRunner Click Spring
0189	"E" Lock	2046	Line Roller Bushing	2964	Clutch Plate Assembly
0202	Bail Arm	2047	Line Roller	2965	Clutch Arm
0204	Bail Arm Screw	2049	Line Roller Screw	2966	Clutch Cam Spacer (B)
0345	Anti-Reverse Lever Screw	2055	Drag Knob	2967	Clutch Cam Spacer (A)
0389	Oscillating Slider Retainer	2057	Seal Plate	2968	Clutch Cam
0390	Oscillating Slider	2062	Line Roller Washer	2970	Dial Retainer
0452	Tension Spring Washer "A"	2110	Slider Retainer Screw	2971	BaitRunner Pawl
0459	Bearing Retainer	2163	Eared Washer	2972	BaitRunner Pawl Spring
0540	Pawl Guide Screw	2615	BaitRunner Lever	2973	Body
0543	Side Cover Screw (B)	2616	Lock Washer	2974	BaitRunner Pawl Guide
0595	Anti-Reverse Pawl Spring	2852	Handle Screw Lock	2975	Dial Click
0596	Pinion Gear	2913	Bail Trip Slide Cam	2976	Free Spool Tension Shaft
0642	Clutch Plate Screw	2915	Pinion Spacer	2977	Free Spool Tension Washer (A)
0654	Bail Spring	2916	Anti-Reverse Cam	2978	Click Gear
0787	Nut Lock Screw	2934	Dial Click Screw	2979	Free Spool Tension Washer (B)
0792	Bearing Retainer Screw	2948	Drag Washer 1	2980	Eared Washer "Brs"
0813	Lever Spring	2949	Spool Assembly	2981	Free Spool Tension Spring
0819	Anti-Reverse Lever	2950	Main Shaft	2982	Free Spool Tension Screw
0839	Anti-Reverse Spring Holder	2951	Rotor	2983	Dial Spacer
0841	Oscillating Gear	2952	Bail Trip Lever	2984	BaitRunner Tension Dial
0902	Anti-Reverse Ratchet	2953	Bail Assembly	2985	BaitRunner Lever Bridge
0930	Ball Bearing	2954	Drive Gear	2986	BaitRunner Lever Arm (R)
0958	Bail Trip Cover Screw	2955	"C" Lock	3165	Seal Plate Screw
0999	Anti-Reverse Pawl Screw			3294	Aluminum Spool