
www.reelschematic.com

SHIMANO®
1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

TO ORDER:
This reel belongs to the "Bantam" series. Please order parts using the abbreviation "BNT" and the part number.



EXPLODED PARTS VIEW

BANTAM® 1000 & 1000 SG

PARTS LIST

PART #	DESCRIPTION
1.	Handle Nut Lock Screw
2.	Handle Nut
3.	Handle Nut Lock Plate
4.	Drive Shaft Retainer Screw
6.	Friction Washer
11.	Right Side Plate Screw
13.	Drive Shaft Bearing
14.	Drag Spring Washer
15.	"D" Washer
16.	Drag Spacer
17.	Pressure Plate
18.	Drag Washer
24.	Pinion Yoke Spring
26.	Drive Shaft Shim
27.	Retractor Spring No. 1
29.	Retractor Spring No. 2
34S.	Centrifugal Brake Weights (Small)
34L.	Centrifugal Brake Weights (Large)
36.	Right Stabilizer Bar Screw
40.	Level Wind Guard
42.	Level Wind Pawl
49.	Left Side Plate Screw
110.	Handle
111.	Drag Tri Star
112.	Cast Control Cap
113.	Cast Control Spacer
114.	Cast Control Spring
115.	Right Side Plate
117.	Drive Gear
118.	Base Drag Washer
119.	Anti Reverse Rachet
120.	Drive Shaft
121.	Pinion Gear
122.	Anti Reverse Dog
123.	Set Plate
124.	Spool Shaft Bearing
125.	Bearing Lock
126.	Spool
127.	Centrifugal Brake Weight (X-Large)
128.	Pawl Cap
129.	Level Wind Gear
130.	Level Wind Bearing-Right
131.	Line Guide
132.	Stabilizer Bar
133.	Level Wind Gear Lock
134.	Left Bearing Spacer
135.	Frame
136.	Left Side Plate
137.	Level Wind Bearing
160.	Right Side Plate

Prices and specifications subject to change without notice.