
www.reelschematic.com

SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718



TO ORDER:
This reel belongs to the "Bantam" series. Please order parts using the abbreviation "BNT" and the part number.

EXPLODED PARTS VIEW

BANTAM® MAG 100 SG

PARTS LIST

PART #	DESCRIPTION
1.	Handle Nut Lock Screw
2.	Handle Nut
3.	Handle Nut Lock Plate
4.	Drive Shaft Retainer Screw
6.	Friction Washer
7.	Drag Tri-Star
8.	Cast Control Cap
9.	Cast Control Spacer
11.	Side Plate Screw
13.	Drive Shaft Bearing
14.	Drag Spring Washer
15.	"D" Washer
16.	Drag Spacer
17.	Pressure Plate
18.	Drag Washer
19.	Drive Gear
20.	Base Drag Washer
21.	Anti Reverse Ratchet
22.	Drive Shaft
24.	Pinion Yoke Spring
25.	Pinion Yoke
26.	Drive Shaft Shim
27.	Retractor Spring #1
28.	Anti Reverse Dog
29.	Retractor Spring #2
32.	Bearing Lock
35.	Left Bearing Spacer
36.	Stabilizer Bar Screw
39.	Level Wind Bearing (Right)
40.	Level Wind Guard
41.	Line Guide
42.	Level Wind Pawl
43.	Pawl Cap
44.	Line Guide Stabilizer Bar
45.	Level Wind Bearing (Left)
60.	Pawl Shim (Optional)
133.	Level Wind Gear Lock
148.	Level Wind Gear
154.	Felt Oil Retainer
181.	Pinion Gear
182.	Spool Shaft Bushing
184.	Magnet Retainer Lock
185.	Magnet Retainer
188.	O Ring
191.	Left Side Plate Screw
192.	Left Stabilizer Bar Screw
193.	Handle
194.	Spool Shaft Bearing
195.	Right Side Plate
196.	Set Plate
197.	Spool (Old Type)
198.	Bearing Spacer
199.	Frame
200.	Magnetic Control Dial
201.	Left Side Plate
265.	Thrust Washer
321.	Spool (convertible)
322.	V-Spool Converter*

Prices and specifications subject to change without notice.

*Can by used with 321 spool only.

JUNE 1986