
www.reelschematic.com

SHIMANO

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

EXPLODED PARTS VIEW



TO ORDER:
This reel belongs to the "Bantam" series. Please order parts using the abbreviation "BNT" and the part number.

BANTAM® MAG-21 SG

PARTS LIST

PART#	DESCRIPTION
1.	Handle Nut Lock Screw
6.	Friction Washer
9.	Cast Control Spacer
11.	Side Plate Screw
13.	Drive Shaft Bearing
14.	Drag Spring Washer
15.	"D" Washer
16.	Drag Spacer
17.	Pressure Plate
18.	Drag Washer
20.	Base Drag Washer
24.	Pinion Yoke Spring
26.	Drive Shaft Shim
32.	Bearing Lock
35.	Bearing Spacer
36.	Stabilizer Bar Screw
39.	Level Wind Bearing
42.	Level Wind Pawl
45.	Level Wind Bearing
60.	Pawl Shim (optional)

PART#	DESCRIPTION
64.	Level Wind Guard
65.	Stabilizer Bar
133.	Level Wind Gear Lock
138.	Handle Nut Lock Plate
141.	Cast Control Cap
145.	Spool Shaft Bushing
149.	Line Guide
151.	Pawl Cap
154.	Felt Oil Retainer
161.	Handle Nut
162.	"C" Lock
165.	Drive Gear
166.	Anti Reverse Ratchet
167.	Pinion Yoke
168.	Drive Shaft
170A.	Anti Reverse Dog
171.	Anti Reverse Switch
172.	Switch Spring
173.	Retractor Spring
175.	Level Wind Gear

PART#	DESCRIPTION
179A.	Cast Control Bushing
182.	Spool Shaft Bushing
184.	Magnet Retainer Lock
185.	Magnet Retainer
188.	O Ring
189.	Magnetic Control Dial
191.	Side Plate Screw
192.	Stabilizer Bar Screw
198.	Bearing Spacer
208B.	Pinion Gear
265.	Thrust Washer
312.	Handle
313.	Drag Tri-Star
314.	Left Side Plate
315.	Set Plate
316.	Spool
317.	Frame
318.	Right Side Plate
324.	V Spool Converter

Prices and specifications subject to change without notice

JUNE 1986