
www.reelschematic.com

SHIMANO®

1987 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718

EXPLODED PARTS VIEW



TO ORDER:
This reel belongs to the "Bantam" series. Please order parts using the abbreviation "BNT" and the part number.

BANTAM® MAG PLUS-™ 150 SG

PARTS LIST

PART#	DESCRIPTION
6.	Friction Washer
9.	Cast Control Spacer
13.	Drive Shaft Bearing
14.	Drag Spring Washer
15.	"D" Washer
16.	Drag Spacer
17.	Pressure Plate
18.	Drag Washer
20.	Base Drag Washer
22.	Drive Shaft
24.	Pinion Yoke Spring
32.	Bearing Lock
39.	Level Wind Bearing Righ'
40.	Level Wind Guard
42.	Level Wind Pawl
44.	Stabilizer Bar
45.	Level Wind Bearing Left
60.	Pawl Shim (optional)
133.	Level Wind Gear Lock

PART#	DESCRIPTION
151.	Pawl Cap
154.	Felt Oil Retainer
162.	"C" Lock
167.	Pinion Yoke
170.	Anti Reverse Dog
184.	Magnet Retainer Lock
185.	Magnet Retainer
188.	O Ring
189.	Magnetic Control Dial
194.	Spool Shaft Bearing
198.	Bearing Spacer
241.	Handle Nut Lock Plate
243.	Drag Tri-Star
246.	Anti Reverse Ratchet
249.	Switch Spring
251.	Retractor Spring
265.	Thrust Washer
268.	Drive Shaft Shim
271.	Drive Gear

PART#	DESCRIPTION
272.	Pinion Gear
273.	Anti Reverse Switch
276.	Level Wind Gear
277.	Left Bearing Spacer
280.	Handle Nut Lock Screw
281.	Handle Nut
282.	Handle
283.	Right Side Plate
284.	Cast Control Cap
285.	Right Side Plate Screw
286.	Set Plate
287.	Spool
288.	Line Guide
289.	Frame
290.	Left Side Plate
291.	Left Side Plate Screw
292.	Left Stabilizer Bar Screw
326A.	V Spool Converter