



※ Please check the head of the "Magnetic Control Dial" here to see whether you have an old or new-type reel.

※ If your reel has an old-type "Magnetic Control Dial" as indicated in the exploded view, please use the parts in the box below the main diagram to order these specific parts. All other part numbers are as shown in the main exploded view.



| BNT No. | PARTS NAMES | BNT No. | PARTS NAMES | BNT No. | PARTS NAMES |
|---------|------------------------|---------|----------------------------|---------|---------------------------------------|
| 0001 | Handle Nut Plate Screw | 0587 | Side Plate Bolt "A" | 0621 | Worm Bearing "B" |
| 0002 | Handle Nut | 0588 | Spool Shaft Bushing | 0623 | Dial Case Screw |
| 0006 | Friction Washer "A" | 0590 | Lock Washer | 0624 | Screw Support |
| 0009 | Cast Control Spacer | 0591 | Flipping Lever | 0644 | Cast Control Cap |
| 0014 | Friction Washer "B" | 0593 | Cam Spring | 0645 | Flipping Lever Screw |
| 0015 | Drag Spring Washer | 0594 | Flipping Cam | 0647 | One-Piece Frame |
| 0016 | Friction Washer "C" | 0595 | Joint Plate | 0648 | Spool Shaft Bushing |
| 0042 | Line Guide Pawl | 0596 | Retractor Spring | 0649 | Thumb Rest |
| 0060 | Spacer (optional) | 0597 | Retractor Spring Guide | 0652 | Left Side Plate |
| 0133 | Worm Shaft Retainer | 0598 | Bushing | 0657 | Clutch Button Guide Pin |
| 0151 | Pawl Cap | 0599 | Drive Gear | 0658 | Flipping Retractor Spring |
| 0184 | Magnet Retainer Lock | 0600 | Idle Gear | 0660 | Spring Spacer (new) |
| 0188 | O Ring | 0601 | Drive Shaft | 0661 | Magnet Retainer Spring (new) |
| 0191 | Right Side Plate Screw | 0602 | Drive Shaft Washer "C" | 0701 | Thrust Washer Spacer (optional) (new) |
| 0277 | Bushing Spacer "B" | 0603 | Pinion Gear | 0702 | Dial O Ring (new) |
| 0330 | Handle Nut Plate | 0604 | Yoke Spring | 0703 | Right Side Plate (new) |
| 0345 | Drive Shaft Washer "B" | 0605 | Yoke | 0704 | Spool (new) |
| 0356 | Worm Bearing "A" | 0606 | Clutch Button | 0705 | Bushing Retainer (new) |
| 0425 | Clutch Button Lock | 0607 | Switch Spring Pin | 0706 | Magnet Retainer (new) |
| 0458 | Bushing "C" | 0608 | Switch Spring | 0707 | Dial Case (new) |
| 0489 | Key Washer "A" | 0609 | Drive Shaft Retainer Screw | 0708 | Magnetic Control Dial (new) |
| 0490 | Drag Washer | 0610 | Drive Shaft Retainer | | |
| 0492 | Key Washer "B" | 0611 | Drive Shaft Bushing | | |
| 0493 | Anti-Reverse Ratchet | 0612 | Anti-Reverse Pawl Pin | 0032 | Bushing Retainer |
| 0581 | Handle Assembly | 0613 | Anti-Reverse Pawl | 0185 | Magnet Retainer |
| 0582 | Star Drag | 0615 | Bushing Retainer | 0625 | Dial Case |
| 0583 | Drive Shaft Bearing | 0616 | Line Guide | 0626 | Magnetic Control Dial |
| 0584 | Side Plate Bolt "C" | 0618 | Worm Shaft | 0646 | Right Side Plate |
| 0585 | Anti-Reverse Switch | 0619 | Lever Wind Guard | 0650R | Spool |
| 0586 | Bolt Retainer | 0620 | Stabilizer Bar | 0651 | Bushing Spacer |