



Part No.	Description	Part No.	Description	Part No.	Description
RD 0026	Ball Bearing	RD 1676	Side Cover Screw	RD 3767	Oscillating Slider Retainer
RD 0041	Drive Gear Washer	RD 2016	Drag Washer "H" (cloth)	RD 3769	Drag Knob
RD 0071	Rotor Nut	RD 2257	Drag Washer "H" (blue)	RD 3794	Drag Knob Screw
RD 0111	Drag Coil Spring	RD 2293	Drive Gear Bushing	RD 3869	Anti-Reverse Lock Out Spring
RD 0345	Anti-Reverse Lever Screw	RD 2346	Drag Washer "C" (cloth)	RD 4270	Anti-Reverse Pawl
RD 0452	Drag Spring Washer	RD 2433	Pressure Screw	RD 4271	Anti-Reverse Cam
RD 0540	Drag Click Screw	RD 2541	Anti-Reverse Pawl Screw	RD 4274	Drag Shaft
RD 0579	Eared Washer "B"	RD 2852	Handle Screw Lock	RD 4281	Pinion Gear
RD 0584	Hold Click Spring	RD 2861	Trigger Cam	RD 4282	Drive Gear
RD 0787	Nut Lock Screw	RD 3359	Line Roller Washer	RD 4290	Main Shaft Assembly
RD 0792	Bearing Retainer Screw	RD 3655	Cover Screw	RD 4310	Drag Click
RD 0826	Key Washer "A"	RD 3678	Rotor	RD 4357	Quick-Fire II Trigger
RD 0930	Ball Bearing	RD 3681	Bail Spring Guide (A)	RD 4359	Bail Arm
RD 0940	Bail Hold Support Screw	RD 3682	Bail Spring	RD 4379	Anti-Reverse Lever
RD 0949	Trigger Screw	RD 3683	Bail Spring Guide (B)	RD 5625	Line Roller Spacer
RD 1008	Handle Lock Washer	RD 3684	Bail Spring Cover	RD 5628	Line Roller Collar
RD 1030	Handle Assembly	RD 3685	Bail Trip Lever	RD 5629	Line Roller Bushing
RD 1310	Line Roller Screw	RD 3686	Counterbalance Cover	RD 5630	Line Roller
RD 1442	Handle Screw Cap	RD 3688	Anti-Reverse Lock Out	RD 6732	Bail Assembly
RD 1506	Multi-Purpose Screw	RD 3692	Anti-Reverse Pawl Spring	RD 6863	Spool Assembly
RD 1511	Lever Spring	RD 3695	Oscillating Gear	RD 7053	Anti-Reverse Ratchet
RD 1520	Anti-Reverse Cam Spring	RD 3747	Slider Retainer Screw	RD 7054	Body Set
RD 1596	Bushing Washer	RD 3766	Oscillating Slider		