
www.reelschematic.com

SHIMANO®

CALAIS®

CL-200-5



Part No.	Description	Part No.	Description	Part Number	Description
BNT0011	Multi-Purpose Screw (A)	BNT2126	Star Drag Nut	BNT2161	Level Wind Guard
BNT0015	Drag Spring Washer	BNT2127	Star Drag Spacer	BNT2162	Worm Bushing (B)
BNT0032	Bearing Retainer	BNT2128	Bearing Washer	BNT2164	Yoke
BNT0060	Spacer (optional)	BNT2129	Star Drag Bearing	BNT2165	Clutch Cam Retainer
BNT0188	"O" Ring	BNT2130	Cast Control Cap	BNT2166	Clutch Cam
BNT0194	Ball Bearing	BNT2131	Spool Tension Spacer (B)	BNT2167	Clutch Pawl
BNT0586	Friction Ring	BNT2132	Spool Tension Spacer (A)	BNT2168	Clutch Pawl Spring
BNT0664	Spacer (B)	BNT2133	Cast Control Click Plate	BNT2169	Clutch Plate
BNT0686	"E" Lock	BNT2134	Click Pin Holder	BNT2170	Ball Bearing
BNT0687	Spacer	BNT2135	Cast Control Click Holder	BNT2171	Clutch Bar Guide (A)
BNT1206	Roller Clutch Inner Tube	BNT2137	Drag Washer (C)	BNT2172	Clutch Bar Guide (B)
BNT1207	Roller Clutch Bearing	BNT2139	Drag Washer (A)	BNT2173	Quick-Fire II Clutch Bar
BNT1211	Key Washer	BNT2141	Idle Gear (A)	BNT2174	Clutch Bar Support
BNT1328	Drive Shaft Retainer	BNT2142	Idle Gear (A) Spacer	BNT2175	Thumb Rest Screw
BNT1362	Turnkey Pawl	BNT2143	Ball Bearing	BNT2176	Spool Assembly
BNT1419	Yoke Spring	BNT144	Drive Shaft Washer	BNT2177	Left Side Plate Spring
BNT1636	Multi-Purpose Screw (B)	BNT2145	Level Wind Protector	BNT2178	Damper (A)
BNT1671	Worm Shaft Washer	BNT2146	Line Guard Screw	BNT2179	Brake Case Screw
BNT1672	"E" Lock	BNT2147	Line Guard Screw Cover	BNT2180	Brake Case
BNT1713	Brake Collar (green)	BNT2148	Thumb Rest	BNT2181	Brake Case Ring Washer
BNT2023	Spool Shaft Clip Holder	BNT2149	Line Guide	BNT2182	Brake Case Ring Spring
BNT2024	Spool Shaft Clip	BNT2150	Line Guide Pawl	BNT2183	Brake Case Ring
BNT2116	Handle Assembly	BNT2151	Pawl Cap	BNT2184	Left Side Plate
BNT2117	Handle Nut	BNT2152	Level Wind Guide	BNT2185	Turnkey Dial
BNT2118	Handle Nut Plate	BNT2153	Line Guard (C)	BNT2187	Drive Gear
BNT2119	Nut Plate Screw	BNT2154	Idle Gear (C)	BNT2188	Pinion Gear
BNT2120	Click Plate Retainer	BNT2155	Worm Shaft	BNT2196	Right Side Plate
BNT2121	Star Drag Click Plate	BNT2156	Worm Bushing (A)	BNT2198	Cast Control Cap Assembly
BNT2122	Click Pin	BNT2157	One-Piece Frame	BNT2343	Drive Shaft
BNT2123	Click Spring	BNT2158	Right Side Plate Screw		
BNT2124	Star Drag	BNT2159	Damper Washer		
BNT2125	Star Drag Spring	BNT2160	Damper (B)	BNT1715	Brake Collar (red)

(120809)