
www.reelschematic.com

# SHIMANO®

## CALAIS®

## CL-200-5




| Part No. | Description | Part No. | Description | Part Number | Description |
|---|---|---|---|---|---|
| BNT0011 | Multi-Purpose Screw (A) | BNT2126 | Star Drag Nut | BNT2161 | Level Wind Guard |
| BNT0015 | Drag Spring Washer | BNT2127 | Star Drag Spacer | BNT2162 | Worm Bushing (B) |
| BNT0032 | Bearing Retainer | BNT2128 | Bearing Washer | BNT2164 | Yoke |
| BNT0060 | Spacer (optional) | BNT2129 | Star Drag Bearing | BNT2165 | Clutch Cam Retainer |
| BNT0188 | "O" Ring | BNT2130 | Cast Control Cap | BNT2166 | Clutch Cam |
| BNT0194 | Ball Bearing | BNT2131 | Spool Tension Spacer (B) | BNT2167 | Clutch Pawl |
| BNT0586 | Friction Ring | BNT2132 | Spool Tension Spacer (A) | BNT2168 | Clutch Pawl Spring |
| BNT0664 | Spacer (B) | BNT2133 | Cast Control Click Plate | BNT2169 | Clutch Plate |
| BNT0686 | "E" Lock | BNT2134 | Click Pin Holder | BNT2170 | Ball Bearing |
| BNT0687 | Spacer | BNT2135 | Cast Control Click Holder | BNT2171 | Clutch Bar Guide (A) |
| BNT1206 | Roller Clutch Inner Tube | BNT2137 | Drag Washer (C) | BNT2172 | Clutch Bar Guide (B) |
| BNT1207 | Roller Clutch Bearing | BNT2139 | Drag Washer (A) | BNT2173 | Quick-Fire II Clutch Bar |
| BNT1211 | Key Washer | BNT2141 | Idle Gear (A) | BNT2174 | Clutch Bar Support |
| BNT1328 | Drive Shaft Retainer | BNT2142 | Idle Gear (A) Spacer | BNT2175 | Thumb Rest Screw |
| BNT1362 | Turnkey Pawl | BNT2143 | Ball Bearing | BNT2176 | Spool Assembly |
| BNT1419 | Yoke Spring | BNT144 | Drive Shaft Washer | BNT2177 | Left Side Plate Spring |
| BNT1636 | Multi-Purpose Screw (B) | BNT2145 | Level Wind Protector | BNT2178 | Damper (A) |
| BNT1671 | Worm Shaft Washer | BNT2146 | Line Guard Screw | BNT2179 | Brake Case Screw |
| BNT1672 | "E" Lock | BNT2147 | Line Guard Screw Cover | BNT2180 | Brake Case |
| BNT1713 | Brake Collar (green) | BNT2148 | Thumb Rest | BNT2181 | Brake Case Ring Washer |
| BNT2023 | Spool Shaft Clip Holder | BNT2149 | Line Guide | BNT2182 | Brake Case Ring Spring |
| BNT2024 | Spool Shaft Clip | BNT2150 | Line Guide Pawl | BNT2183 | Brake Case Ring |
| BNT2116 | Handle Assembly | BNT2151 | Pawl Cap | BNT2184 | Left Side Plate |
| BNT2117 | Handle Nut | BNT2152 | Level Wind Guide | BNT2185 | Turnkey Dial |
| BNT2118 | Handle Nut Plate | BNT2153 | Line Guard (C) | BNT2187 | Drive Gear |
| BNT2119 | Nut Plate Screw | BNT2154 | Idle Gear (C) | BNT2188 | Pinion Gear |
| BNT2120 | Click Plate Retainer | BNT2155 | Worm Shaft | BNT2196 | Right Side Plate |
| BNT2121 | Star Drag Click Plate | BNT2156 | Worm Bushing (A) | BNT2198 | Cast Control Cap Assembly |
| BNT2122 | Click Pin | BNT2157 | One-Piece Frame | BNT2343 | Drive Shaft |
| BNT2123 | Click Spring | BNT2158 | Right Side Plate Screw | | |
| BNT2124 | Star Drag | BNT2159 | Damper Washer | | |
| BNT2125 | Star Drag Spring | BNT2160 | Damper (B) | BNT1715 | Brake Collar (red) |

(120809)