
www.reelschematic.com

CALCUTTA 400B

A-RB



(1RH316400U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0009	Cast Control Spacer	1620	Eared Washer	1704	Click Plate
0032	Bearing Retainer	1627	Yoke	1705	Click Spring
0042	Line Guide Pawl	1628	Clutch Cam Retainer	1706	Click Switch Spring
0060	Spacer	1629	Clutch Cam	1838	Washer
0133	E Lock	1631	Clutch Plate	1853	Key Washer
0151	Pawl Cap	1633	Level Wind Guard	2061	Drag Washer
0188	O Ring	1634	Level Wind Guide	2062	Drag Washer
0425	E Lock	1635	Worm Bushing A Retainer	2063	Drag Washer
0586	O Ring	1636	Screw	2098	Cast Control Cap
0623	Screw	1639	Idle Gear A / Click Gear	2473	Star Drag Spacer
0686	E Lock	1641	Side Plate Bolt	2926	Roller Clutch Inner Tube
0770	Screw	1643	Clutch Bar Support	2927	Ball Bearing
0799	Friction Washer	1646	Screw	3107	Line Guide
0819	Drive Shaft Bushing	1647	Washer	3290	Washer
1201	Retractor Spring Collar	1648	Idle Gear B	3309	Brake Collar
1215	Anti-Reverse Ratchet	1649	Idle Gear Shaft	3356	Handle Assembly
1223	Retractor Spring	1650	Brake Ring	3357	Star Drag
1227	Push Nut (SPN-2)	1651	Click Shaft	3358	Right Side Plate
1237	Screw	1652	Screw	3359	Drive Gear
1243	Worm Bushing B	1654	Click Link	3360	Pinion Gear
1245	Spacer	1656	Click Pawl	3361	Anti-Reverse Pawl
1293	Retractor Spring Pin	1658	Click Switch	3362	Set Plate
1302	Screw	1659	Lock Washer	3363	Spool Assembly
1306	Clutch Pawl	1660	Spacer B	3364	Clutch Bar Guide A
1307	Clutch Pawl Spring	1663	Handle Nut Plate	3365	Clutch Bar Guide B
1337	Spacer	1696	Cast Control Spacer B	3366	Quick-Fire II Clutch Bar
1455	Drag Spring Washer H	1697	Spool Tension Spring	3367	One-Piece Frame
1476	Spacer	1698	Side Plate Bolt	3368	Left Side Plate
1494	Washer	1699	Worm Bushing A	3385	Yoke Spring
1613	Drag Spring Washer L	1700	Worm Shaft	3441	Handle Nut
1616	Screw	1702	Washer	3442	Drive Shaft
1618	Key Washer	1703	Idle Gear C		

(170209)