
www.reelschematic.com

CALCUTTA 400BSV

A-RB



(1RH317400U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0009	Cast Control Spacer	1627	Yoke	1726	Click Plate
0032	Bearing Retainer	1628	Clutch Cam Retainer	1853	Key Washer
0188	O Ring	1629	Clutch Cam	2061	Drag Washer
0425	E Lock	1631	Clutch Plate	2062	Drag Washer
0586	O Ring	1636	Screw	2063	Drag Washer
0623	Screw	1639	Idle Gear A / Click Gear	2098	Cast Control Cap
0686	E Lock	1641	Side Plate Bolt	2473	Star Drag Spacer
0770	Screw	1646	Screw	2926	Roller Clutch Inner Tube
0799	Friction Washer	1649	Idle Gear Shaft	2927	Ball Bearing
0819	Drive Shaft Bushing	1650	Brake Ring	3290	Washer
1201	Retractor Spring Collar	1651	Click Shaft	3309	Brake Collar
1215	Anti-Reverse Ratchet	1652	Screw	3357	Star Drag
1223	Retractor Spring	1654	Click Link	3359	Drive Gear
1227	Push Nut (SPN-2)	1656	Click Pawl	3360	Pinion Gear
1237	Screw	1658	Click Switch	3361	Anti-Reverse Pawl
1245	Spacer	1659	Lock Washer	3362	Set Plate
1293	Retractor Spring Pin	1660	Spacer B	3363	Spool Assembly
1302	Screw	1663	Handle Nut Plate	3364	Clutch Bar Guide A
1306	Clutch Pawl	1696	Cast Control Spacer B	3365	Clutch Bar Guide B
1307	Clutch Pawl Spring	1697	Spool Tension Spring	3366	Quick-Fire II Clutch Bar
1337	Spacer	1698	Side Plate Bolt	3368	Left Side Plate
1455	Drag Spring Washer H	1705	Click Spring	3369	Handle Assembly
1476	Spacer	1706	Click Switch Spring	3370	Right Side Plate
1494	Washer	1719	Front Crossbar Screw	3371	One-Piece Frame
1613	Drag Spring Washer L	1720	Front Crossbar	3385	Yoke Spring
1616	Screw	1722	Clutch Bar Support	3441	Handle Nut
1618	Key Washer	1724	Clutch Bar Support Sleeve	3442	Drive Shaft
1620	Eared Washer	1725	Screw		

(170209)