
www.reelschematic.com



CT700S

Parts #	Description	Parts #	Description	Parts #	Description
BNT0006	Friction Washer	BNT1734	Right Side Plate Bolt (A)	BNT1761	Yoke
BNT0009	Cast Control Spacer (A)	BNT1735	Right Side Plate (B)	BNT1762	Clutch Button
BNT0032	Bearing Retainer	BNT1737	Pressure Rivet	BNT1763	Retractor Spring
BNT0188	"O" Ring	BNT1738	Set Plate (A) Screw	BNT1764	Retractor Spring Pin
BNT0194	Ball Bearing	BNT1739	Key Washer	BNT1765	Set Plate (A)
BNT0268	Washer	BNT1740	Drag Washer (D)	BNT1766	Drive Shaft Bushing
BNT0425	"E" Lock	BNT1741	Eared Washer (C)	BNT1767	Drive Shaft Washer
BNT0586	Bolt Retainer	BNT1742	Drag Washer (B)	BNT1768	Clutch Button Guide Pin
BNT0664	Spacer (B)	BNT1743	Key Washer (E)	BNT1769	Clutch Pawl Pin
BNT0686	"E" Lock	BNT1744	Drive Gear	BNT1776	Spool Assembly
BNT0770	Multi-Purpose Screw	BNT1745	Drag Washer (G)	BNT1777	Click Gear Assembly
BNT0995	Handle Nut	BNT1746	Anti-Reverse Ratchet	BNT1778	"E" Lock
BNT1252	Right Side Plate Bolt Washer	BNT1747	Drive Shaft	BNT1780	Click Pawl
BNT1419	Spring	BNT1748	Retraction Cam Washer	BNT1781	Click Spring
BNT1455	Drag Spring Washer (H)	BNT1749	Retraction Cam	BNT1783	Left Side Plate Screw
BNT1613	Drag Spring Washer (L)	BNT1750	Cam Backing Plate	BNT1785	Click Switch Spring
BNT1672	"E" Lock	BNT1751	Plastic Gear Plate	BNT1786	Click Switch
BNT1696	Cast Control Spacer (B)	BNT1752	Clutch Retraction Spring	BNT1787	Left Side Plate
BNT1701	Brake Collar (Gray)	BNT1753	Pivot Pin	BNT1858	Eared Washer (F)
BNT1727	Handle Nut Plate	BNT1754	Yoke Spring	BNT1859	Right Side Plate
BNT1728	Handle Assembly	BNT1755	Pinion Gear	BNT1860	Left Side Plate Bolt
BNT1729	Star Drag	BNT1756	Clutch Spacer	BNT1861	One-Piece Frame
BNT1730	Star Drag Washer	BNT1756	Clutch Plate	BNT1862	Set Plate (B)
BNT1731	Roller Clutch Inner Tube	BNT1758	Clutch Pawl	BNT1865	Spool Tension Spring
BNT1732	Roller Clutch Bearing	BNT1759	Yoke Pin		
BNT1733	Cast Control Cap	BNT1760	Clutch Pawl Spring	BNT1707	Brake Collar (Clear)