
www.reelschematic.com

CALCUTTA TE 200DC




(1RH315200U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0011	Drive Shaft Retainer Screw	2433	Drag Washer (A)	2950	Roller Clutch Inner Tube
0015	Drag Spring Washer	2434	Anti-Reverse Ratchet	3031	Digital Control Screw
0032	Bearing Retainer	2436	Idle Gear (A)	3060	Handle Nut Plate Screw
0060	Spacer (optional)	2437	Drive Shaft Retainer	3061	Handle Nut Plate
0133	"E" Lock	2439	Level Wind Guide	3062	Handle Nut
0234	"E" Lock	2440	Idle Gear (C)	3063	Handle Assembly
0664	Spacer (B)	2441	Worm Bushing (A)	3064	Star Drag
0686	"E" Lock	2443	Level Wind Guard	3065	Star Drag Bearing
0687	Spacer	2444	Pinion Gear	3066	Right Side Plate Screw (C) (s
1218	Idle Gear (A) Spacer	2445	Yoke Spring	3067	Right Side Plate
1237	Shield Screw	2446	Yoke	3068	Right Side Plate Screw (A)
1636	Clutch Cam Screw	2447	Clutch Cam	3069	Side Plate Shaft
1672	"E" Lock	2448	Clutch Plate	3070	Right Side Plate Screw (B) (l
1696	Cast Control Spacer (B)	2449	Clutch Pawl	3071	Cast Control Cap
1838	Worm Shaft Spacer	2450	Clutch Pawl Spring	3072	Cast Control Click Plate
2120	Click Plate Retainer	2451	Set Pin	3073	Click Pin Holder
2121	Star Drag Click	2452	Clutch Bar Guide (A)	3074	Cast Control Click Holder
2122	Click Pin	2453	Clutch Bar Support	3075	Cast Control Cap Assembly
2123	Click Spring	2454	Clutch Bar Guide (B)	3076	"O" Ring
2125	Star Drag Spring	2455	Quick-Fire II Clutch Bar	3077	Drive Shaft
2126	Star Drag Nut	2456	Line Guide	3078	Frame Shield
2127	Star Drag Spacer	2457	Pawl Cap	3079	Worm Shaft
2128	Bearing Washer	2458	Anti-Reverse Pawl Pin	3080	One-Piece Frame
2150	Line Guide Pawl	2460	Worm Bushing (B)	3081	Spool Assembly
2165	Clutch Cam Retainer	2927	Ball Bearing	3082	Magnetic Plate
2430	Key Washer	2937	Ball Bearing	3083	Digital Control Assembly
2431	Drag Washer (C)	2948	Ball Bearing	3084	Left Side Plate
2432	Drive Gear	2949	Roller Clutch Bearing		

(15

Printed in

CALCUTTA TE 201DC



(1RH315201U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0011	Drive Shaft Retainer Screw	2434	Anti-Reverse Ratchet	2950	Roller Clutch Inner Tube
0015	Drag Spring Washer	2436	Idle Gear (A)	3031	Digital Control Screw
0032	Bearing Retainer	2437	Drive Shaft Retainer	3060	Handle Nut Plate Screw
0060	Spacer (optional)	2439	Level Wind Guide	3061	Handle Nut Plate
0133	"E" Lock	2440	Idle Gear (C)	3064	Star Drag
0234	"E" Lock	2443	Level Wind Guard	3065	Star Drag Bearing
0664	Spacer (B)	2445	Yoke Spring	3066	Left Side Plate Screw (C) (sh
0686	"E" Lock	2448	Clutch Plate	3068	Left Side Plate Screw (A)
0687	Spacer	2451	Set Pin	3069	Side Plate Shaft
1218	Idle Gear (A) Spacer	2452	Clutch Bar Guide (A)	3070	Left Side Plate Screw (B) (lor
1237	Shield Screw	2453	Clutch Bar Support	3071	Cast Control Cap
1636	Clutch Cam Screw	2457	Pawl Cap	3072	Cast Control Click Plate
1672	"E" Lock	2458	Anti-Reverse Pawl Pin	3073	Click Pin Holder
1696	Cast Control Spacer (B)	2551	Drive Gear	3074	Cast Control Click Holder
1838	Worm Shaft Spacer	2554	Worm Bushing (A)	3075	Cast Control Cap Assembly
2120	Click Plate Retainer	2555	Pinion Gear	3076	"O" Ring
2121	Star Drag Click	2556	Yoke	3079	Worm Shaft
2122	Click Pin	2557	Clutch Cam	3081	Spool Assembly
2123	Click Spring	2558	Clutch Pawl	3082	Magnetic Plate
2127	Star Drag Spacer	2559	Clutch Pawl Spring	3085	Handle Nut
2128	Bearing Washer	2560	Clutch Bar Guide (B)	3086	Handle Assembly
2150	Line Guide Pawl	2561	Quick-Fire II Clutch Bar	3087	Left Side Plate
2201	Star Drag Spring	2562	Line Guide	3088	Drive Shaft
2202	Star Drag Nut	2564	Worm Bushing (B)	3089	Frame Shield
2213	Clutch Cam Retainer	2927	Ball Bearing	3090	One-Piece Frame
2430	Key Washer	2937	Ball Bearing	3091	Digital Control Assembly
2431	Drag Washer (C)	2948	Ball Bearing	3092	Right Side Plate
2433	Drag Washer (A)	2949	Roller Clutch Bearing		

(15