


RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3747	Slider Retainer Screw	6787	Bail Spring Cover
0071	Rotor Nut	3848	Bail Spring Guide (A)	6790	Counterbalance Cover
0452	Drag Spring Washer	3849	Bail Spring Guide (B)	7289	Push Button Collar
0540	Multi-Purpose Screw	3851	Bail Trip Lever	7290	Push Button
0574	Drag Washer “C” (cloth)	3853	Anti-Reverse Lock Out	7291	Spool Assembly
0579	Eared Washer “B”	3854	Anti-Reverse Lock Out Spring	7292	Main Shaft
0584	Hold Click Spring	3855	Lock Out Spring Holder	7293	Bail Assembly
0642	Side Cover Screw	3856	Anti-Reverse Pawl	7295	Ball Bearing
0779	Multi-Purpose Screw	3857	Anti-Reverse Pawl Spring	7297	Anti-Reverse Cam
0787	Nut Lock Screw	4049	Large Hole Washer	7298	Anti-Reverse Lever
0792	Bearing Retainer Screw	4096	Drag Shaft	7300	Oscillating Slider Retainer
0848	Small Hole Washer	4097	Pressure Screw	7301	Oscillating Slider Inner
1008	Handle Lock Washer	4099	Drag Knob Screw	7302	Oscillating Slider
1891	Bail Spring Cover Screw	4111	Pinion Gear	7303	Oscillating Gear
2257	Drag Washer “H” (blue)	4112	Drive Gear	7304	Oscillating Gear Bushing
2283	Anti-Reverse Pawl Screw	4367	Line Roller Screw	7305	Drag Spring
2419	Handle Screw Cap	4568	Bail Arm	7306	Drag Knob
2852	Handle Screw Lock	5625	Line Roller Spacer	7307	Handle Assembly
3359	Line Roller Washer	5628	Line Roller Collar	7336	Rotor
3397	Bail Spring	5629	Line Roller Bushing	7337	Ball Bearing
3402	Cover Screw	5630	Line Roller	7338	Body Set
3471	Anti-Reverse Cam Spring	5690	Anti-Reverse Lever Screw		
3744	Drag Click	5996	Locking Spring		

(130308)