



| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|---|---|---|---|---|---|
| 0041 | Drive Gear Washer | 3747 | Slider Retainer Screw | 6794 | Bail Trip Lever |
| 0071 | Rotor Nut | 3848 | Bail Spring Guide (A) | 6795 | Counterbalance Cover |
| 0452 | Drag Spring Washer | 3849 | Bail Spring Guide (B) | 7289 | Push Button Collar |
| 0540 | Multi-Purpose Screw | 3853 | Anti-Reverse Lock Out | 7290 | Push Button |
| 0574 | Drag Washer "C" (cloth) | 3854 | Anti-Reverse Lock Out Spring | 7295 | Ball Bearing |
| 0579 | Eared Washer "B" | 3855 | Lock Out Spring Holder | 7297 | Anti-Reverse Cam |
| 0584 | Hold Click Spring | 3856 | Anti-Reverse Pawl | 7298 | Anti-Reverse Lever |
| 0642 | Side Cover Screw | 3857 | Anti-Reverse Pawl Spring | 7300 | Oscillating Slider Retainer |
| 0779 | Multi-Purpose Screw | 4049 | Large Hole Washer | 7301 | Oscillating Slider Inner |
| 0787 | Nut Lock Screw | 4096 | Drag Shaft | 7302 | Oscillating Slider |
| 0792 | Bearing Retainer Screw | 4097 | Pressure Screw | 7303 | Oscillating Gear |
| 0848 | Small Hole Washer | 4099 | Drag Knob Screw | 7304 | Oscillating Gear Bushing |
| 1008 | Handle Lock Washer | 4111 | Pinion Gear | 7305 | Drag Spring |
| 1891 | Bail Spring Cover Screw | 4112 | Drive Gear | 7306 | Drag Knob |
| 2257 | Drag Washer "H" (blue) | 4367 | Line Roller Screw | 7307 | Handle Assembly |
| 2283 | Anti-Reverse Pawl Screw | 4568 | Bail Arm | 7309 | Spool Assembly |
| 2419 | Handle Screw Cap | 5625 | Line Roller Spacer | 7310 | Main Shaft |
| 2852 | Handle Screw Lock | 5628 | Line Roller Collar | 7311 | Bail Assembly |
| 3359 | Line Roller Washer | 5629 | Line Roller Bushing | 7337 | Ball Bearing |
| 3397 | Bail Spring | 5630 | Line Roller | 7339 | Rotor |
| 3402 | Cover Screw | 5690 | Anti-Reverse Lever Screw | 7340 | Body Set |
| 3471 | Anti-Reverse Cam Spring | 5996 | Locking Spring | | |
| 3744 | Drag Click | 6787 | Bail Spring Cover | | |

(130308)