


RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3681	Bail Spring Guide (A)	5628	Line Roller Collar
0071	Rotor Nut	3682	Bail Spring	5629	Line Roller Bushing
0452	Drag Spring Washer	3683	Bail Spring Guide (B)	5630	Line Roller
0540	Multi-Purpose Screw	3747	Slider Retainer Screw	5690	Anti-Reverse Lever Screw
0579	Eared Washer “B”	3765	Drag Click	5990	Push Button Collar
0584	Hold Click Spring	3794	Drag Knob Screw	5994	Push Button
0779	Multi-Purpose Screw	3863	Rotor	5996	Locking Spring
0787	Nut Lock Screw	3865	Bail Spring Cover	7295	Ball Bearing
0792	Bearing Retainer Screw	3866	Bail Trip Lever	7305	Drag Spring
0826	Key Washer “A”	3867	Counterbalance Cover	7317	Bail Assembly
0848	Small Hole Washer	3869	Anti-Reverse Lock Out Spring	7321	Anti-Reverse Cam
1008	Handle Lock Washer	3873	Anti-Reverse Pawl Spring	7323	Oscillating Slider Retainer
1442	Handle Screw Cap	4049	Large Hole Washer	7324	Oscillating Slider Inner
1511	Lever Spring	4274	Drag Shaft	7325	Oscillating Slider
1520	Anti-Reverse Cam Spring	4275	Drag Knob	7326	Oscillating Gear
1596	Bushing Washer	4306	Lock Out Spring Holder	7331	Main Shaft
2016	Drag Washer “H” (cloth)	4307	Anti-Reverse Lock Out	7337	Ball Bearing
2257	Drag Washer “H” (blue)	4308	Anti-Reverse Pawl	7342	Pinion Gear
2346	Drag Washer “C” (cloth)	4362	Side Cover Screw	7343	Drive Gear
2433	Pressure Screw	4367	Line Roller Screw	7345	Match Spool Assembly
2541	Anti-Reverse Pawl Screw	4379	Anti-Reverse Lever	7346	Side Cover
2852	Handle Screw Lock	4395	Handle Assembly	7347	Body
3359	Line Roller Washer	4572	Bail Arm		
3402	Cover Screw	5625	Line Roller Spacer		

(130308)