



A-RB

(1RH291053U)

BNT No.	PARTS NAMES	BNT No.	PARTS NAMES	BNT No.	PARTS NAMES
0011	Screw	2144	Washer	3151	Star Drag
0015	Drag Spring Washer	2150	Line Guide Pawl	3152	Star Drag Nut
0032	Bearing Retainer	2154	Idle Gear C	3153	Screw
0060	Spacer	2161	Level Wind Guard	3154	Right Side Plate
0623	Screw	2162	Worm Bushing B	3155	Cast Control Cap
0664	Spacer B	2164	Yoke	3156	Key Washer
0686	E Lock	2165	Clutch Cam Retainer	3157	Drag Washer C
0987	Screw	2167	Clutch Pawl	3158	Drive Gear
1106	Star Drag Spring	2168	Clutch Pawl Spring	3159	Drive Shaft
1328	Drive Shaft Retainer	2224	Spool Tension Spacer A	3160	Worm Shaft
1344	C Lock	2361	Drag Washer A	3161	Line Guard
1419	Yoke Spring	2379	Screw	3162	Stabilizer Bar
1473	Screw	2392	Star Drag Click Plate	3163	Pinion Gear
1499	Screw	2400	Idle Gear A	3164	Clutch Guard
1636	Screw	2402	Worm Bushing A	3165	Quick-Fire II Clutch Bar
1672	E Lock	2406	Clutch Cam	3166	One-Piece Frame
1696	Cast Control Spacer B	2407	Clutch Plate	3167	Thumb Rest
1715	Brake Collar (red)	2414	Left Side Plate Spring	3168	Line Guide
1866	Spacer	2927	Ball Bearing	3169	Pawl Cap
1996	Spool Tension Spring	2937	Ball Bearing	3170	Left Side Frame Plate
2023	Spool Shaft Clip Holder	2948	Ball Bearing	3171	Spool Assembly
2024	Spool Shaft Clip	2949	Roller Clutch Bearing	3172	Left Side Plate
2117	Handle Nut	3022	Roller Clutch Inner Tube	3173	Turnkey Dial
2122	Click Pin	3148	Screw	3196	Brake Case
2123	Click Spring	3149	Handle Nut Plate		
2127	Star Drag Spacer	3150	Handle Assembly	3174	Reel Seat Spacer