
www.reelschematic.com

SHIMANO®

1994 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 92718



CITICA
CI-201 94

CI201B

PART #	DESCRIPTION
BNT0015	Drag Spring Washer
BNT0032	Bearing Retainer
BNT0042	Line Guide Pawl
BNT0194	Ball Bearing
BNT0425	Drive Shaft Lock
BNT0664	Spacer (B)
BNT0817	Multi Purpose Screw
BNT0819	Drive Shaft Bushing
BNT0830	Spacer (optional)
BNT0880	Spool Shaft Bushing
BNT0987	Multi Purpose Screw
BNT1092	Pawl Cap
BNT1106	Star Drag Spring
BNT1133	Yoke/Turnkey Pawl Spring
BNT1206	Roller Clutch Inner Tube
BNT1207	Roller Clutch Bearing
BNT1211	Key Washer
BNT1212	Drag Washer (C)
BNT1214	Drag Washer (A)
BNT1289	Star Drag Spacer

PART #	DESCRIPTION
BNT1317	Brake Collar (red)
BNT1344	"C" Lock
BNT1356	Brake Case Retainer Screw
BNT1362	Turnkey Pawl
BNT1467	Level Wind Guard
BNT1469	Line Guide
BNT1486	Star Drag
BNT1487	Cast Control Cap Assembly
BNT1489	Side Plate Screws
BNT1490	Anti-Reverse Ratchet
BNT1492	Idle Gear
BNT1494	Drive Shaft Washer (B)
BNT1497	Drive Shaft Cover Screw
BNT1498	Worm Shaft Assembly
BNT1499	Clutch Plate Screw
BNT1502	Spacer (optional)
BNT1506	Line Guard
BNT1508	Brake Case
BNT1510	Turnkey Dial

PART #	DESCRIPTION
BNT1511	Handle Assembly
BNT1512	Star Drag Nut
BNT1515	Drive Shaft
BNT1516	Drive Shaft Cover
BNT1517	Clutch Plate
BNT1519	Yoke
BNT1520	Clutch Cam Retainer
BNT1521	Clutch Cam
BNT1522	Clutch Pawl
BNT1523	Clutch Pawl Spring
BNT1525	One-Piece Frame
BNT1526	Quick-Fire II Clutch Bar
BNT1529	Drive Shaft Washer (A)
BNT1531	Spool Assembly
BNT1533	Left Side Plate
BNT1534	Drive Gear
BNT1535	Pinion Gear
BNT1536	Thumb Rest
BNT1537	Right Side Plate