



# CORIOLIS

## CO-200B 95

CO200B

Part #	Description	Part #	Description	Part #	Description
BNT0015	Drag Spring Washer	BNT1456	Drive Gear	BNT1479	Magnet Retainer
BNT0042	Line Guide Pawl	BNT1458	Anti-Reverse Ratchet	BNT1480	Dial Case
BNT0124	Ball Bearing	BNT1460	Clutch Plate	BNT1481	Magnet Control Dial
BNT0194	Ball Bearing	BNT1461	Yoke	BNT1483	Lock Spring
BNT0425	Drive Gear Retainer	BNT1462	Clutch Cam Retainer	BNT1484	Lock Screw Cap
BNT0661	Magnet Retainer Spring	BNT1463	Clutch Cam	BNT1551	Dial Friction Washer
BNT0664	Spacer (B)	BNT1464	Clutch Pawl	BNT1598	Handle Assembly
BNT0799	Friction Washer	BNT1465	Clutch Pawl Spring	BNT1599	Star Drag
BNT0810	Drag Washer	BNT1466	Worm Shaft Assembly	BNT1600	Cast Control Cap Assembly
BNT0817	Muilt Purpose Screw	BNT1467	Level Wind Guard	BNT1601	Right Side Plate
BNT0819	Drive Shaft Bushing	BNT1468	Level Wind Protector	BNT1602	Key Washer
BNT0820	Pinion Gear	BNT1469	Line Guide	BNT1603	Drive Shaft Washer
BNT0830	Spacer (optional)	BNT1471	Drive Shaft Cover	BNT1604	Drive Shaft
BNT1092	Pawl Cap	BNT1473	Multi Purpose Screw	BNT1605	Thumb Rest
BNT1206	Roller Clutch Inner Tube	BNT1474	One-Piece Frame	BNT1606	Spool
BNT1207	Roller Clutch Bearing	BNT1475	Quick-Fire II Clutch Bar	BNT1607	Left Side Plate
BNT1419	Yoke Spring	BNT1476	Drive Shaft Washer (D)		
BNT1452	Side Plate Screws	BNT1478	Magnet Holder		