
# SHIMANO

## CURADO

# CU151MGM



(51RL782A61X)

| # | Part No. | BNT No. | Description | # | Part No. | BNT No. | Description | # | Part No. | BNT No. | Description |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 1 | 10DV5 | 6913 | Screw | 43 | 10S3Y | 5756 | Screw | 89 | 100GW | 5971 | O Ring |
| 2 | 101E6 | 6914 | Handle Nut Plate | 44 | 109T1 | 5329 | Drive Shaft Retainer | 90 | 10L1Q | 5348 | Screw |
| 4 | 100NC | 6126 | Handle Knob Seal | 45 | 10KHG | | E Lock | 92 | 101UN | 6933 | Washer |
| 5 | 10LFA | 5714 | Screw | 46 | 149BE | | Click Spring | 94 | 10SSN | 5680 | Washer |
| 6 | 10PXZ | 5334 | Bushing | 48 | 10FJB | 4874 | Pawl Cap | 95 | 103LE | 4814 | Screw |
| 7 | 104FH | 6555 | Washer | 49 | 10CFU | 6701 | Washer | 96 | 10G6D | 5715 | Washer |
| 9 | 10KXW | 5314 | Click Plate Retainer | 50 | 10BHQ | 5383 | Line Guide Pawl | 97 | 108WS | 2427 | O Ring |
| 10 | 10J26 | 5860 | Star Drag Click Plate | 51 | 108WQ | 4729 | O Ring | 99 | 10KNH | 5681 | Spring |
| 11 | 10MFC | 5316 | Click Pin | 52 | 10R51 | 6907 | Line Guide Pawl Holder Assembly | 100 | 103L7 | 4817 | Screw |
| 12 | 10BT2 | 2123 | Click Spring | 53 | 105NK | 7199 | E Lock | 101 | 10CLF | 4819 | Idle Gear |
| 14 | 10A70 | 4124 | Star Drag Spring | 54 | 10SRL | 5659 | Idle Gear | 102 | 10GQZ | 4932 | Click Spring |
| 16 | 10J1P | 6450 | Star Drag Spacer | 55 | 10S8K | 6926 | Worm Shaft | 104 | 10GR3 | 7198 | Washer |
| 17 | 109F5 | 5376 | Washer | 56 | 10T3X | 6927 | Level Wind Guard | 401 | 101DW | 5722 | Handle Nut |
| 18 | 100SE | 6655 | Washer | 58 | 100U9 | 5942 | Yoke Spring | 403 | 149T7 | | Star Drag |
| 19 | 105BK | | Ball Bearing | 60 | 10LV0 | 5944 | Screw | 404 | 10A3U | 6949 | Star Drag Nut |
| 20 | 142V6 | | Cast Control Cap | 61 | 100US | 5945 | Clutch Cam Retainer | 407 | 149TA | | Drive Shaft |
| 21 | 10896 | 1696 | Cast Control Spacer (B) | 62 | 10190 | 5308 | Washer | 408 | 149TC | | Level Wind Protector |
| 22 | 1085F | 2224 | Cast Control Spacer | 67 | 10LF4 | 5948 | Screw | 411 | 100W0 | 6102 | Clutch Cam |
| 23 | 1054D | 5319 | Bearing Retainer | 68 | 10EX8 | 3927 | Ball Bearing | 412 | 10MQM | 4911 | Clutch Pawl Assembly |
| 24 | 105C3 | 4343 | Ball Bearing | 69 | 100S4 | 6928 | Screw | 413 | 10TMC | 5362 | Clutch Pawl Spring |
| 25 | 101GT | 5503 | O Ring | 73 | 10SXB | 5668 | Screw | 414 | 10TME | 5363 | Clutch Plate |
| 26 | 100BL | 6918 | Bearing Spacer | 74 | 105NB | 2717 | E Lock | 415 | 10R5C | 6944 | Clutch Guard Assembly |
| 27 | 105BP | 4194 | Ball Bearing | 75 | 10LCQ | 5328 | Screw | 416 | 10DRX | 6953 | Clutch Bar Guide B |
| 28 | 10R22 | 5320 | O Ring | 77 | 100UT | 5956 | Stabilizer Bar | 417 | 10SBC | 6954 | Clutch Button |
| 29 | 10LCY | 5932 | Screw | 78 | 100G7 | 6931 | Level Wind Guard Bushing | 418 | 14AYW | | Frame Assembly |
| 31 | 1005E | 5780 | Roller Clutch Bearing | 79 | 10FJZ | 4588 | Washer | 419 | 10S8N | 6946 | Brake Case |
| 32 | 13UCY | | Roller Clutch Inner Tube | 80 | 105NC | 1672 | E Lock | 420 | 10DRY | 6955 | B Side Plate Cam Lever |
| 33 | 100BK | 6921 | Key Washer | 81 | 108PY | 4893 | Washer | 421 | 10263 | 5972 | Brake Dial |
| 34 | 106XT | 4625 | Drag Washer | 82 | 100BH | 6932 | O Ring | 422 | 14AYX | | B Side Plate Assembly |
| 36 | 10CHY | 4590 | Drag Washer | 83 | 10TM7 | 7202 | O Ring | 501 | 149T2 | | Handle Assembly |
| 37 | 100BJ | 6922 | Anti-Reverse Ratchet | 84 | 10MD0 | 5803 | Spool Clutch Pin | 505 | 1001Q | 6957 | Yoke |
| 39 | 10JDY | 5327 | Idle Gear Spring | 85 | 10EZ7 | 5218 | O Ring | 601 | 14AYT | | A Side Plate Assembly |
| 40 | 10HJG | 5310 | Idle Gear Pin | 86 | 1497F | | Spool Assembly | 602 | 10DRA | 6959 | Drive Gear |
| 41 | 101K8 | 5654 | Idle Gear A | 87 | 10EX5 | 5346 | Spacer | 603 | 10SB0 | 6960 | Pinion Gear |
| 42 | 108WU | 6924 | O Ring | 88 | 101DR | 5676 | Brake Ring Gear | | | | |

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(250210)_002

ReelSchematic