



Part No.	Description	Part No.	Description	Part No.	Description
RD 0041	Drive Gear Washer	RD 3455	Spool Washer	RD 5583	Anti-Reverse Lock Out Spring
RD 0050	Anti-Reverse Lever Screw	RD 3471	Anti-Reverse Cam Spring	RD 5584	Anti-Reverse Lock Out
RD 0080	Line Roller	RD 3645	Drag Knob	RD 5585	Rotor Lock
RD 0642	Side Cover Screw	RD 3665	Slider Retainer Screw	RD 5586	Pinion Bushing (back)
RD 0779	Multi-Purpose Screw	RD 3673	Oscillating Gear	RD 5587	Drive Gear
RD 0815	Line Roller Washer	RD 3848	Bail Spring Guide (A)	RD 5591	Bail Spring Cover
RD 1008	Handle Lock Washer	RD 3856	Anti-Reverse Pawl	RD 5592	Bail Assembly
RD 1025	Handle Assembly	RD 3857	Anti-Reverse Pawl Spring	RD 5593	Rotor Assembly
RD 1427	Spool Support	RD 3858	Anti-Reverse Cam	RD 5594	Bail Trip Lever
RD 1442	Handle Screw Cap	RD 4051	Bail Spring	RD 5595	Counterbalance Cover
RD 1514	Bushing Washer	RD 4295	Bail Spring Guide (B)	RD 5791	Bushing
RD 1891	Multi-Purpose Screw	RD 4351	Anti-Reverse Lever	RD 5793	Oscillating Slider
RD 2283	Anti-Reverse Pawl Screw	RD 4367	Line Roller Screw	RD 6847	Spool Assembly
RD 2293	Drive Gear Bushing	RD 4388	Bail Arm	RD 6848	Side Cover
RD 2852	Handle Screw Lock	RD 5581	Main Shaft	RD 6849	Body