



Part No.	Description	Part No.	Description	Part No.	Description
RD 0041	Drive Gear Washer	RD 2852	Handle Screw Lock	RD 4367	Line Roller Screw
RD 0050	Anti-Reverse Lever Screw	RD 3503	Spool Washer	RD 4392	Bail Arm
RD 0080	Line Roller	RD 3665	Slider Retainer Screw	RD 5177	Bail Assembly
RD 0540	Multi-Purpose Screw	RD 3676	Drag Knob	RD 5599	Rotor Assembly
RD 0642	Side Cover Screw (small)	RD 3677	Main Shaft	RD 5600	Anti-Reverse Lock Out Spring
RD 0779	Multi-Purpose Screw	RD 3681	Bail Spring Guide (A)	RD 5601	Anti-Reverse Lock Out
RD 0815	Line Roller Washer	RD 3682	Bail Spring	RD 5602	Anti-Reverse Pawl
RD 1008	Handle Lock Washer	RD 3695	Oscillating Gear	RD 5603	Rotor Lock
RD 1030	Handle Assembly	RD 3874	Anti-Reverse Cam	RD 5604	Pinion Bushing (back)
RD 1442	Handle Screw Cap	RD 4264	Bail Spring Guide (B)	RD 5605	Drive Gear
RD 1511	Lever Spring	RD 4267	Bail Trip Lever Washer	RD 5646	Anti-Reverse Pawl Spring
RD 1520	Anti-Reverse Cam Spring	RD 4317	Bail Spring Cover	RD 5792	Bushing
RD 1957	Bushing Washer	RD 4318	Bail Trip Lever	RD 5794	Oscillating Slider
RD 2293	Drive Gear Bushing	RD 4351	Anti-Reverse Lever	RD 6850	Spool Assembly
RD 2516	Spool Support	RD 4360	Side Cover Flange	RD 6851	Side Cover
RD 2541	Anti-Reverse Pawl Screw	RD 4362	Side Cover Screw (large)	RD 6852	Body