


SHIMANO

FX

FXC3000FC



Part No.	Description	Part No.	Description	Part No.	Description
RD 3402	Screw	RD14833	Spool Support B	RD17391	Screw
RD 3455	Spool Washer	RD15425	Pinion Gear Bushing	RD17395	Rear Protector
RD 4798	Screw	RD15431	Oscillating Slider	RD17853	Screw
RD 5431	Drive Gear Bushing	RD15434	Oscillating Guide	RD18536	Washer
RD 6684	Line Roller Spacer	RD15588	Anti-Reverse Lever	RD18549	Roller Clutch Assembly
RD 7295	Ball Bearing	RD15990	Oscillating Gear	RD18686	Drag Washer Retainer
RD 7337	Ball Bearing	RD17145	Anti-Reverse Cam Spring	RD18865	Key Washer
RD 7969	Eared Washer	RD17151	Main Shaft	RD19010	Washer
RD 9367	Line Roller Bushing	RD17153	Pinion Gear	RD20207	Drive Gear
RD 9368	Line Roller	RD17154	Anti-Reverse Cam	RD20214	Drag Knob Assembly
RD 9369	Line Roller Washer	RD17332	Screw	RD20218	Handle Screw Cap
RD 9411	Bail Assembly	RD17372	Screw	RD20224	Rotor
RD 9427	Bail Spring Guide A	RD17373	Rotor Nut	RD20228	Body
RD 9525	Bail Arm	RD17374	Screw	RD20230	Side Cover
RD10064	Bail Spring Cover	RD17378	Screw	RD20236	Spool Assembly
RD10301	Drag Washer	RD17382	Screw	RD20238	Handle Assembly
RD14832	Spool Support A	RD17390	Bail Spring	RD20351	Bail Trip Lever