
www.reelschematic.com

# EXPLODED PARTS VIEWS OF BSM-2201W



## ■PARTS LIST OF BSM-2201W

| BNT No. | PARTS NAMES |
|---|---|
| 6 | Friction Washer "A" |
| 9 | Cast Control Spacer |
| 14 | Friction Washer "B" |
| 15 | Drag Spring Washer |
| 16 | Friction Washer "C" |
| 32 | Bearing Retainer |
| 36 | Stabilizer Bar Screw "A" |
| 42 | Line Guide Pawl |
| 45 | Worm Bearing "B" |
| 60 | Spacer(optional) |
| 133 | Worm Shaft Retainer |
| 162 | Drive Shaft Retainer |
| 184 | Magnet Retainer Lock |
| 188 | O Ring |
| 194 | Ball Bearing |
| 198 | Bearing Spacer |
| 242 | Handle Assembly |
| 244 | Bashing |
| 265 | Spacer(optional) |
| 268 | Drive Shaft Washer "A" |
| 277 | Bearing Spacer "B" |
| 280 | Handle Nut Plate Screw |
| 285 | Left Side Plate Screw |
| 291 | Right Side Plate Screw |
| 292 | Stabilizer Bar Screw "B" |
| 306 | Handle Nut |
| 311 | Magnet Retainer |
| 330 | Handle Nut Plate |
| 335 | Bearing Washer "A" |
| 340 | Switch Spring |
| 341 | Switch Spring Lock |
| 356 | Worm Bearing "A" |
| 357 | Line Guide |

| BNT No. | PARTS NAMES |
|---|---|
| 358 | Pawl Cap |
| 365 | Magnetic Control Dial |
| 399 | Retractor Guide Screw |
| 423 | Yoke Spring |
| 446 | Yoke |
| 448 | Retractor Spring |
| 487 | Cast Control Cap |
| 489 | Key Washer "A" |
| 490 | Drag Washer |
| 496 | Drive Shaft Washer "C" |
| 509 | Drive Shaft |
| 519 | Level Wind Guard |
| 522 | Stabilizer Bar |
| 535 | Anti-Reverse Switch |
| 538 | Retractor Guide |
| 540 | Drive Shaft Washer "B" |
| 541 | Key Washer "B" |
| 542 | Anti-Reverse Ratchet |
| 543 | Idle Gear |
| 551 | Star Drag |
| 552 | Left Side Plate Cover |
| 554 | Clutch Button Attachment |
| 555 | Drive Gear |
| 556 | Pinion Gear |
| 557 | Anti-Reverse Pawl |
| 558 | Set Plate Assembly |
| 560 | Right Side Plate |
| 575 | Spool |
| 576 | Worm Shaft |
| 578 | Level Wind Protector |
| 579 | Left Side Plate |
| 580 | Frame |
| | |