



TO ORDER: USE RD PREFIX
WITH PART NUMBER

PARTS LIST

RD #	DESCRIPTION	RD #	DESCRIPTION	RD #	DESCRIPTION
0026	Ball Bearing	1676	Side Cover Screw	2330	Anti-Reverse Ratchet
0041	Drive Gear Washer	1712	Anti-Reverse Pawl Screw	2331	Anti-Reverse Lock Out
0071	Rotor Nut	1888	Anti-Reverse Lock Out Spring	2332	Bearing Retainer
0111	Drag (Coil) Spring	1890	Bushing Washer	2334	Anti-Reverse Pawl
0345	Anti-Reverse Lever Screw	1932	Anti-Reverse Pawl Spring	2335	Anti-Reverse Cam
0452	Drag Spring Washer "A"	2016	Drag Washer "H2" (White)	2336	Worm Bearing (Front)
0540	Anti-Reverse Pawl Screw	2048	Line Roller Washer	2337	Worm Shaft Spacer
0543	Side Cover Screw (B)	2108	Eared Washer "B"	2339	Worm Shaft
0584	Hold Click Spring	2257	Drag Washer "H1"	2342	Side Cover Screw (B)
0787	Nut Lock Screw	2288	Worm Bearing	2343	Oscillating Slider Retainer
0792	Bearing Retainer Screw	2292	Anti-Reverse Lever	2344	Oscillating Slider
0826	Key Washer "A"	2293	Drive Gear Bushing	2346	Drag Washer "C2" (White)
0930	Ball Bearing	2298	Spacer	2353	Drag Programmer Screw
0940	Bail Trip Cam Screw	2299	Oscillating Slider Bushing	2397	Rotor
0949	Trigger Screw	2300	Oscillating Pawl	2406	Drive Gear
1007	Lock Washer Retainer	2309	Slider Retainer Screw	2428	Pinion Gear
1008	Handle Lock Washer	2318	Main Shaft	2429	Idle Gear
1302	Line Roller Screw	2320	Quick-Fire II Trigger	2432	Drag Shaft
1315	Pre-Set Spring	2321	Rotor Side Cover	2433	Pressure Screw
1366	Drag Click	2322	Bail Assembly	2434	Pre-Set Spring Cover
1442	Handle Screw Cap	2323	Line Roller Bushing	2436	Pre-Set Cam
1506	Bail Spring Cover Screw	2324	Bail Spring Guide (B)	2670	Spool Assembly
1508	Bail Spring Guide A	2325	Sic Ceramic Roller	2671	Side Cover
1509	Bail Spring	2326	Arm Cam	2672	Body
1511	Lever Spring	2327	Bail Spring Cover	2673	Pre-Set Ring
1520	Anti-Reverse Cam Spring	2328	Bail Trip Lever	2674	Drag Knob
1596	Bushing Washer	2329	Bail Trip Lever Screw	2675	Handle Assembly