




JHX™ 4000F



Part No.	Description
RD 0026	Ball Bearing
RD 0041	Drive Gear Washer
RD 0071	Rotor Nut
RD 0345	Anti-Reverse Lever Screw
RD 0543	Side Cover Screw (small)
RD 0787	Nut Lock Screw
RD 0792	Bearing Retainer Screw
RD 0940	Multi-Purpose Screw
RD 1008	Handle Lock Washer
RD 1030	Handle Assembly
RD 1310	Line Roller Screw
RD 1442	Handle Screw Cap
RD 1506	Multi-Purpose Screw
RD 1511	Lever Spring
RD 1520	Anti-Reverse Cam Spring
RD 1676	Side Cover Screw (large-black)
RD 2293	Drive Gear Bushing
RD 2516	Spool Support
RD 2541	Anti-Reverse Pawl Screw

Part No.	Description
RD 2852	Handle Screw Lock
RD 2934	Flange Screw
RD 3359	Line Roller Washer
RD 3449	Spool Assembly
RD 3503	Spool Washer
RD 3655	Cover Screw
RD 3665	Slider Retainer Screw
RD 3676	Drag Knob
RD 3677	Main Shaft
RD 3681	Bail Spring Guide (A)
RD 3682	Bail Spring
RD 3683	Bail Spring Guide (B)
RD 3690	Pinion Gear
RD 3694	Drive Gear
RD 3695	Oscillating Gear
RD 3696	Oscillating Slider
RD 3868	Lock Out Spring Holder
RD 3869	Anti-Reverse Lock Out Spring
RD 3870	Anti-Reverse Lock Out

Part No.	Description
RD 3871	Bushing Washer
RD 3872	Anti-Reverse Pawl
RD 3873	Anti-Reverse Pawl Spring
RD 3874	Anti-Reverse Cam
RD 3886	Bail Trip Lever
RD 4351	Anti-Reverse Lever
RD 4362	Side Cover Screw (large-silver)
RD 4572	Bail Arm
RD 5625	Line Roller Spacer
RD 5628	Line Roller Collar
RD 5629	Line Roller Bushing
RD 5630	Line Roller
RD 6797	Bail Spring Cover
RD 6798	Bail Assembly
RD 6799	Rotor
RD 6800	Counterbalance Cover
RD 6801	Body Assembly
RD 6804	Sideplate Assembly