


# SHIMANO

## SLX

## SLX151XGA



(51RL608A41X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description
BNT1672	E Lock	BNT5362	Clutch Pawl Spring	BNT5962	Screw
BNT1696	Cast Control Spacer B	BNT5372	Drive Gear	BNT6095	Handle Nut
BNT2123	Click Spring	BNT5376	Drag Spring Washer	BNT6098	Drive Shaft
BNT2127	Star Drag Spacer	BNT5380	Drag Washer C	BNT6100	Pinion Gear
BNT2144	Drive Shaft Washer	BNT5383	Line Guide Pawl	BNT6101	Yoke
BNT2224	Cast Control Spacer A	BNT5386	Ball Bearing	BNT6102	Clutch Cam
BNT2396	Roller Clutch Bearing	BNT5395	Star Drag	BNT6103	Clutch Plate
BNT2717	E Lock	BNT5409	Drive Shaft Bushing	BNT6105	Frame
BNT3208	Star Drag Click Plate	BNT5503	O Ring	BNT6106	Clutch Bar Guide B
BNT4124	Star Drag Spring	BNT5609	Screw	BNT6107	Clutch Button
BNT4130	Drag Washer A	BNT5641	Handle Nut Plate	BNT6108	Clutch Bar Guide A
BNT4343	Ball Bearing	BNT5654	Idle Gear A	BNT6109	Dial Case
BNT4588	Washer	BNT5659	Idle Gear C	BNT6110	Right Side Plate Cam Lever
BNT4729	O Ring	BNT5681	Spring	BNT6370	Screw
BNT4868	Key Washer	BNT5713	Handle Knob Seal	BNT6555	Washer
BNT4874	Pawl Cap	BNT5714	Screw	BNT6701	Spacer
BNT4893	Washer	BNT5930	Cast Control Cap	BNT6913	Screw
BNT4911	Clutch Pawl Assembly	BNT5932	Screw	BNT6932	O Ring
BNT4932	Click Spring	BNT5933	Roller Clutch Inner Tube	BNT6949	Star Drag Nut
BNT5218	O Ring	BNT5937	Screw	BNT7195	Spool Assembly
BNT5264	Anti-Reverse Ratchet	BNT5938	Line Guide Assembly	BNT7198	Washer
BNT5308	Washer	BNT5939	Worm Shaft	BNT7199	E Lock
BNT5310	Idle Gear Pin	BNT5940	Level Wind Guard	BNT7202	O Ring
BNT5316	Click Pin	BNT5942	Yoke Spring	BNT7203	Washer
BNT5319	Bearing Retainer	BNT5944	Screw	BNT7207	Handle Assembly
BNT5320	O Ring	BNT5945	Clutch Cam Retainer	BNT7208	Level Wind Protector
BNT5327	Idle Gear Spring	BNT5948	Screw	BNT7210	Left Side Plate
BNT5329	Drive Shaft Retainer	BNT5951	Screw	BNT7211	Clutch Guard
BNT5331	Spacer	BNT5952	Screw	BNT7368	Right Side Plate
BNT5334	Bushing	BNT5956	Stabilizer Bar		
BNT5346	Spacer	BNT5958	Spool Clutch Pin		