



2000F 99

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4639	Bail Spring Guide (A)	5180	Drag Knob
0041	Drive Gear Washer	4640	Bail Spring	5182	Rotor Nut
0050	Anti-Reverse Lever Screw	4641	Bail Spring Guide (B)	5183	Main Shaft
0642	Side Cover Screw	4642	Bail Arm Screw	5189	Anti-Reverse Cam
0930	Ball Bearing	4643	Bail Arm Bushing	5190	Anti-Reverse Lever
1008	Handle Lock Washer	4649	Spacer	5192	Oscillating Slider
1427	Spool Support	4650	Bail Hold Support Shaft	5194	Spool Assembly
1520	Anti-Reverse Cam Spring	4652	Lever Spring Guide (B)	5547	Handle Assembly
1891	Multi-Purpose Screw	4653	Lever Spring	5625	Line Roller Spacer
2404	"E" Lock	4654	Lever Spring Guide (A)	5628	Line Roller Collar
2852	Handle Screw Lock	4656	Trip Lever Spacer	5629	Line Roller Bushing
3309	Line Roller Screw	4658	Clutch Cover Screw	5630	Line Roller
3359	Line Roller Washer	4659	Roller Clutch Assembly	5654	Pinion Gear
3402	Bail Spring Cover Screw (small)	4661	Anti-Reverse Cam Ring	5655	Drive Gear
3455	Spool Washer	4692	Bail Trip Lever	5658	Bail Assembly
3665	Slider Retainer Screw	4792	Bail Arm	5659	Body Assembly
3673	Oscillating Gear	4795	Bail Hold Support Spacer	5660	Rotor Assembly
4421	Handle Screw Cap	4798	Roller Clutch Screw		