


SHIMANO

SAROS S A-RB

SAR-4000F



(1SE764000U)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0050	Screw	RD 8172	Handle Knob Nut	RD11425	Handle Knob I.D. Plate
RD 0071	Rotor Nut	RD 8758	Click Spring	RD11465	Handle Knob Shaft Collar
RD 0642	Screw	RD 8776	Oil Cap	RD11778	Handle Screw Cap
RD 0787	Screw	RD 8912	Bail Hold Support Guard	RD11795	Drag Knob
RD 1891	Screw	RD 8999	Click Pin	RD11796	Spool Assembly
RD 2266	Drag Washer	RD 9001	Bail Trip Lever	RD11797	Main Shaft
RD 2267	Eared Washer	RD 9005	Roller Clutch Assembly	RD11798	Line Roller
RD 2516	Spool Support	RD 9008	Anti-Reverse Cam Spring	RD11799	Bail Arm
RD 3282	Screw	RD 9009	Anti-Reverse Lever	RD11800	Rotor
RD 3503	Spool Washer	RD 9010	Idle Gear	RD11801	Pinion Gear
RD 3747	Screw	RD 9016	Oscillating Gear	RD11802	Bail Trip Strike
RD 4150	Screw	RD 9017	Oscillating Guide	RD11803	Drive Gear
RD 4661	Anti-Reverse Cam Ring	RD 9019	Oscillating Guide Retainer	RD11804	Side Cover
RD 4749	Screw	RD 9020	Oscillating Guide Plate	RD11805	Oscillating Slider Inner
RD 5690	Screw	RD 9022	Screw	RD11806	Oscillating Slider
RD 5947	Screw	RD 9432	Bail Spring Cover	RD11807	Rear Protector
RD 6482	Screw	RD10420	Bearing Spacer	RD11808	Body
RD 7127	Anti-Reverse Cam	RD10421	Line Roller Collar	RD11911	Handle Shank Assembly
RD 7617	Screw	RD10423	Line Roller Bushing	RD11912	Handle Assembly
RD 7787	Bail Spring Guide A	RD10429	Line Roller Support	RD13185	Ball Bearing
RD 7926	Screw	RD10752	Spring Guide A Support	RD13241	Ball Bearing
RD 7927	Washer	RD10753	Bail Spring	RD13269	Ball Bearing
RD 8147	Friction Ring	RD10756	Bail Spring Seat	RD13374	Ball Bearing
RD 8170	Handle Knob	RD11137	Bail Assembly	RD13928	Drag Washers Retainer
RD 8171	Washer	RD11146	Washer	RD13929	Key Washer